

PortableGrand

DGX-650B/DGX-650WH

Pedal Unit LP-7AWH(OPTION)

SERVICE MANUAL



DGX-650B



DGX-650WH

■ CONTENTS

SPECIFICATIONS	3
PANEL LAYOUT	4
CIRCUIT BOARD LAYOUT & WIRING	6
BLOCK DIAGRAM	8
DISASSEMBLY PROCEDURE	9
LSI PIN DESCRIPTION	20
CIRCUIT BOARDS	24
DM Circuit Board Test Method	33
TEST PROGRAM	34
BACKUP	39
INITIALIZATION	39
SYSTEM BOOTING FLOW CHART	40
PARTS LIST (DGX-650B/DGX-650WH)	
PARTS LIST (LP-7A/LP-7AWH)	
OVERALL CIRCUIT DIAGRAM	

As for an optional LP-7A/LP-7AWH pedal unit,
refer to the LP-7A/LP-5A service manual
(CL 001812).

IMPORTANT NOTICE

This manual has been provided for the use of authorized Yamaha Retailers and their service personnel. It has been assumed that basic service procedures inherent to the industry, and more specifically Yamaha Products, are already known and understood by the users, and have therefore not been restated.

WARNING: Failure to follow appropriate service and safety procedures when servicing this product may result in personal injury, destruction of expensive components and failure of the product to perform as specified. For these reasons, we advise all Yamaha product owners that all service required should be performed by an authorized Yamaha Retailer or the appointed service representative.

IMPORTANT: This presentation or sale of this manual to any individual or firm does not constitute authorization certification, recognition of any applicable technical capabilities, or establish a principal-agent relationship of any form.

The data provided is believed to be accurate and applicable to the unit(s) indicated on the cover. The research engineering, and service departments of Yamaha are continually striving to improve Yamaha products. Modifications are, therefore, inevitable and changes in specification are subject to change without notice or obligation to retrofit. Should any discrepancy appear to exist, please contact the distributor's Service Division.

WARNING: Static discharges can destroy expensive components. Discharge any static electricity your body may have accumulated by grounding yourself to the ground bus in the unit (heavy gauge black wires connect to this bus.)

IMPORTANT: Turn the unit OFF during disassembly and parts replacement. Recheck all work before you apply power to the unit.

WARNING: This product contains chemicals known to the State of California to cause cancer, or birth defects or other reproductive harm.

DO NOT PLACE SOLDER, ELECTRICAL/ELECTRONIC OR PLASTIC COMPONENTS IN YOUR MOUTH FOR ANY REASON WHAT SO EVER!

Avoid prolonged, unprotected contact between solder and your skin! When soldering, do not inhale solder fumes or expose eyes to solder/ flux vapor!

If you come in contact with solder or components located inside the enclosure of this product, wash your hands before handling food.

IMPORTANT NOTICE FOR THE UNITED KINGDOM

Connecting the Plug and Cord

IMPORTANT: The wires in this mains lead are coloured in accordance with the following code:
 BLUE : NEUTRAL
 BROWN : LIVE

As the colours of the wires in the mains lead of this apparatus may not correspond with the coloured markings identifying the terminals in your plug proceed as follows:

The wire which is coloured BLUE must be connected to the terminal which is marked with the letter N or coloured BLACK.

The wire which is coloured BROWN must be connected to the terminal which is marked with the letter L or coloured RED.

Making sure that neither core is connected to the earth terminal of the three pin plug.

• This applies only products distributed by Yamaha-Kemble music (U.K.) Ltd. (2 wires)

■ WARNING

Components having special characteristics are marked  and must be replaced with parts having specification equal to those originally installed.

■ SAVING DATA

Saving and backing up your data

Some data items are automatically saved as backup data in the internal memory even if you turn the power off.


Saved data may be lost due to malfunction or incorrect operation. Save important data to a USB storage device/or other external device such as a computer.

SPECIFICATIONS

Size/Weight	Dimensions	(W x D x H)	1,397 x 445 x 146 mm (55" x 17-1/2" x 5-3/4") with keyboard stand: 1,399 x 445 x 761 mm (55-1/16" x 17-1/2" x 29-15/16")
	Weight		22.5 kg (49 lbs. 10 oz.) with keyboard stand: 29.5 kg (65 lbs. 1 oz.)
Control Interface	Keyboard	Number of Keys	88
		Type	Graded Hammer Standard (GHS) Keyboard
		Touch Response	Soft, Medium, Hard, Fixed
	Other Controllers	Pitch Bend	Yes
		Type	Full Dot LCD
		Size	320 x 240 dots
		Color	Monochrome
		Contrast	Yes
		Score Display Function	Yes
		Lyrics Display Function	Yes
	Panel	Language	English
		Language	English
Voices	Tone Generation	Piano Sound	Pure CF Sound Engine
		Damper Resonance	Yes
	Polyphony	Number of Polyphony (Max.)	128
	Preset	Number of Voices	147 + 15 Drum/SFX Kits + 381 XGlite
		Featured Voices	1 Natural! Voice, 9 Live! Voices, 8 Sweet! Voices, 7 Cool! Voices
Effects	Compatibility		GM, XGlite
	Types	Reverb	35 types
		Chorus	44 types
		DSP	237 types
		Master EQ	5 types
		Intelligent Acoustic Control (IAC)	Yes
	Functions	Dual	Yes
		Split	Yes
		Panel Sustain	Yes (Function Menu)
		Number of Preset Styles	195
		Fingering	Multi Finger, Full Keyboard, AI Fingered
Accompaniment Styles	Preset	Style Control	INTRO, MAIN x 2, FILL-IN, ENDING
		External Styles	Yes (SFF GE)
		Music Database	305
	Other Features	One Touch Setting (OTS)	Yes
		Style Recommender	Yes
Songs	Preset	Number of Preset Songs	100
		Number of Songs	5
		Number of Tracks	6 (5 Melody + 1 Chord)
	Recording	Data Capacity	Approx. 30,000 notes for 1 user song (when only "melody" tracks are recorded)
		Compatible Data Format	SMF (Format 0, Format 1), XF
Audio Recorder	Length of Recording (max.)	Playback	SMF (Format 0)
		Recording	80 minutes per single recording
	Compatible Data Format	Recording	.wav
Functions	Registration	Number of Buttons	4 (x 8 banks)
		Lesson	Yamaha Education Suite (Y.E.S.)
		Demonstration	Waiting, Your tempo, Minus one, Repeat & Learn, Chord Dictionary
	Overall Controls	Metronome	Yes
		Tempo Range	5-280
		Transpose	-12 to 0, 0 to +12
		Tuning	Yes
	Miscellaneous	PIANO Button	Portable Grand Button
		Storage	Approx. 1.7MB
		External Drives	USB Flash Memory
Storage and Connectivity	Connectivity	DC IN	DC IN 12V
		Headphones/Output	x 1
		Sustain Pedal	x 1
		Pedal Unit	x 1
		USB TO DEVICE	Yes
		USB TO HOST	Yes
		AUX IN (Stereo Mini)	Yes
Amplifiers and Speakers	Amplifiers		6W x 2
	Speakers		12cm x 2 + 5cm x 2
Power Supply	Power Supply		Adaptor (PA-150 or the equivalent)
	Power Consumption		13W
Accessories	Included Accessories		- Owner's Manual - Data List - Keyboard Stand - Footswitch - Music Rest - AC Power Adaptor (PA-150 or an equivalent recommended by Yamaha) *1 - Online Member Product Registration *2 *1: May not be included depending on your particular locale. Check with your Yamaha dealer. *2: The PRODUCT ID on the sheet will be needed when you fill out the User Registration form.
	Optional Accessories (May not be available depending on your locale.)		- AC Power Adaptor: - Users within U.S.A. or Europe: PA-150 or an equivalent recommended by Yamaha - Others: PA-5D, PA-150 or an equivalent - Headphones: HPE-150 - Pedal Unit: LP-7A/7AWH - Footswitch: FC4/5 - USB MIDI Interface for iPhone/iPod touch/iPad: i-UX1



PANEL LAYOUT

Front Panel




Front Panel

- ① [⏻] (Standby/On) switch
- ② [MASTER VOLUME] control
- ③ [DEMO/BGM] button
- ④ [SCORE] button
- ⑤ [LYRICS] button
- ⑥ [REC] button
- ⑦ LESSON START
 - [WAITING] button
 - [YOUR TEMPO] button
 - [MINUS ONE] button
- ⑧ [SMART CHORD] button
- ⑨ [STYLE RECOMMENDER] button
- ⑩ Song Track
 - [1]–[5], [A] buttons
 - Lesson
 - [R] and [L] buttons
- ⑪ [METRONOME ON/OFF] button
- ⑫ [TEMPO/TAP] button
- ⑬ SONG/AUDIO
 - [REPEAT&LEARN] button
 - [A-B REPEAT] button
 - [REW] button
 - [FF] button
 - [PAUSE] button
 - [START/STOP] button
- ⑭ STYLE
 - [ACMP ON/OFF] button
 - [INTRO/ENDING/rit.] button
 - [MAIN/AUTO FILL] button
 - [SYNC STOP] button
 - [SYNC START] button
 - [START/STOP] button
- ⑮ REGIST MEMORY
 - [BANK], [1]–[4] buttons
- ⑯ CATEGORY [◀] and [▶] buttons
- ⑰ [EXIT] button
- ⑱ [EXECUTE] button
- ⑲ DATA ENTRY
 - Dial, Number buttons [0]–[9],
 - [+] and [-] buttons
- ⑳ [FILE CONTROL] button
- ㉑ [FUNCTION] button
- ㉒ [PORTABLE GRAND] button
- ㉓ [SONG/AUDIO] button
- ㉔ [STYLE] button
- ㉕ [VOICE] button
- ㉖ [MUSIC DATABASE] button
- ㉗ [SPLIT ON/OFF] button
- ㉘ [DUAL ON/OFF] button
- ㉙ [HARMONY ON/OFF] button
- ㉚ [PITCH BEND] wheel
- ㉛ [USB TO DEVICE] terminal
- ㉜ Compatible Formats



Rear Panel



Rear Panel


- 33** [CONTRAST] knob
- 34** [USB TO HOST] terminal
- 35** [SUSTAIN] jack
- 36** [PEDAL UNIT] jack
- 37** [AUX IN] jack
- 38** [PHONES/OUTPUT] jack
- 39** DC IN jack

“Press & Hold” symbol


By holding down one of the buttons having this symbol, you can call up an alternate function, other than the one called up when simply pressing.

■ CIRCUIT BOARD LAYOUT&WIRING

• Upper case < Bottom view >



• Bottom board



Location	Parts No.	Connector Assembly	Destination		Remarks
(K2)	MFA27350	FLEXIBLE FLAT CABLE	GHL88M-CN2	DM-CN001	Already connected to GHL88M
(600)	ZF629300	FLEXIBLE FLAT CABLE	DM-CN005	PNL-CN1	12P L=80mm
(630)	ZF629400	FLEXIBLE FLAT CABLE	DM-CN006	PNR-CN2	15P L=90mm
(650)	ZF508900	FLEXIBLE FLAT CABLE PDN	DM-CN007	PEDAL-CN701	6P L=90mm
(640)	ZF629600	FLEXIBLE FLAT CABLE	DM-CN008	AJACK-CN402	18P L=90mm
(620)	ZF509100	FLEXIBLE FLAT CABLE DJK	DM-CN009	DJACK-CN410	5P L=130mm
(700)	(ZF51010)*	CONNECTOR ASSEMBLY PWR	DM-CN013	AJACK-CN422	
(710)	(ZF51020)*	CONNECTOR ASSEMBLY SPB	DM-CN012	AJACK-CN415	
(S60)	(ZF51030)*	CONNECTOR ASSEMBLY SPA	AJACK-CN418	Woofer	
(670)	(ZF51040)*	CONNECTOR ASSEMBLY TWL	AJACK-CN419	Tweeter(L)	
(680)	(ZF51050)*	CONNECTOR ASSEMBLY TWR	AJACK-CN420	Tweeter(R)	
(WH102)	(ZF51060)*	WIRING ASSEMBLY SSW	AJACK-CN101	PWR-CN903	Already connected to PWR 2P L=150mm *1
(730)	(ZF51070)*	WIRING ASSEMBLY MVR	AJACK-CN403	MVR-CN902	4P L=95mm *1
(W1)	(ZF63380)*	WIRING ASSEMBLY DCC	AJACK-CN407	AJACK-CN408	Already connected to both. 4P L=45mm
(690)	(ZF51080)*	WIRING ASSEMBLY PTB	AJACK-CN103	PB-CN401	3P L=755mm *1
(WH101)	(ZF62920)*	WIRING ASSEMBLY ENC	PNR-CN3	ENC-CN901	Already connected to both. 3P L=70mm
(660)	(ZF86850)*	CONNECTOR ASSEMBLY USB	DM-CN10	DJACK-CN409	
				USB-CN411	
(L60)	(WB09210)*	WIRING ASSEMBLY BL	LCD ASSEMBLY-60	AJACK-CN423	*1
(L1)	WU967500	LCD UNIT	LCD ASSEMBLY-10	DM-CN002	FFC cable has installed to LCD unit.

The parts with "()" in "Part No." are not available as spare parts.

*1 Edge mark is adjusted to Pin 1 mark (△ mark).

28CA1-2001116092

DISASSEMBLY PROCEDURE

CAUTION:

- 1) Flat cable's contacts are visible from the back.
Pay attention not to insert and install the cable to the connector inversely.
- 2) Be surto attach the removed filament tape just as it was before removal.



Front Side (Printed Side)



Back side

1. Bottom Board Assembly


(Time required: About 8 minutes)

- 1-1 Remove the five (5) screws marked [940A]. The lower case F can then be removed. (Fig.1)
- 1-2 Remove the four (4) screws marked [940B] and the guide screw marked [950A]. The lower case L can then be removed. (Fig.1)
- 1-3 Remove the four (4) screws marked [940C] and the guide screw marked [950B]. The lower case R can then be removed. (Fig.1)
- 1-4 Remove the thirty (30) screws marked [940D]. The bottom board assembly can then be separated from the upper case assembly. (Fig.1)

* When the lower case L is assembled, tighten the screws marked [940B] in the order of 1, 2, 3 and 4. (Fig.1)

* When the lower case R is assembled, tighten the screws marked [940C] in the order of 1, 2, 3 and 4. (Fig.1)

< Bottom view >




1 - 4 : The order of the screw tightening

Fig.1

2. Circuit Boards and Assemblies (Upper Case Part) (Time required: About 9 minutes)


- 2-1 Separate the upper case assembly from the bottom board assembly. (See procedure 1.)
- 2-2 After removing the upper case assembly, remove the following screws. Each circuit board and assembly can then be removed. (Fig.2)(Table 1)

< Bottom view >



< Bottom view >

1 - 2 : The order of the screw tightening



< Rear view >




Fig.2

Circuit Board and Assembly	Screw Ref.No. / Part Name	QTY	Fig.
DM Circuit Board	900A (*1)	4	2
AJACK Circuit Board	900B (*1) (*2)	6	2
	900C	2	2
DJACK Circuit Board	900D (*1)	2	2
USB Circuit Board	900E (*4)	3	2
PNR Circuit Board & (*3) ENC Circuit Board	900F (*1)	7	2
	900G (*1) (*6)	3	2
	Encoder Knob (*8)	1	2-3
MKO Circuit Board (*5)	900H	2	2
PWR Circuit Board	900I (*1)	2	2
	Push Knob (*7)	1	2-2
MVR Circuit Board	900J (*1)	3	2
	Volume Knob (*9)	1	2-4
PB Circuit Board Wheel Assembly	900K (*1)	2	2
Speaker (Tweeter) (L)	900L	2	2
Speaker (Tweeter) (R)	900M	2	2
PEDAL Circuit Board	910A	1	2
Key Block L	60A	6	2
Key Block R	60B	6	2

- *1 When assembling it, tighten the screw marked 1, 2 and other screws in this order. (Fig.2)
- *2 As for the screw at the location of A, it is tightened together with a cord holder. (Fig.2)
- *3 The PNR and the ENC circuit boards are connected with a board-in connector. (Fig.2)
- *4 As for the three (3) screws, they are tightened together with a bracket. (Fig.2)
- *5 The MKO circuit board is used as a flat cable holder. (Fig.2)
- *6 As for the screw at the location of B, it is tightened together with a cord holder. (Fig.2)
- *7 Push Knob (See Fig.2-2.)
- *8 Encoder Knob (See Fig.2-3.)
- *9 Volume Knob (See Fig.2-4.)

Table 1




Fig.2-2




Fig.2-3




Fig.2-4

3. LCD Assembly

(Time required: About 10 minutes)

- 3-1 Separate the upper case assembly from the bottom board assembly. (See procedure 1.)
- 3-2 Remove the DM circuit board. (See procedure 2.)
- 3-3 Remove the four (4) screws marked [900N]. The LCD assembly can then be removed. (Fig.3)

* *When the LCD assembly is assembled, tighten the screws marked [900N] in the order of 1, 2 at the condition that pushed it to the keyboard side. (Fig.3)*

4. PNL Circuit Board

(Time required: About 10 minutes)

- 4-1 Separate the upper case assembly from the bottom board assembly. (See procedure 1.)
- 4-2 Remove the MKO circuit board. (See procedure 2.)
- 4-3 Separate the GHL keyboard assembly from the upper case assembly. (See procedure 6.)
- 4-4 Remove the twelve (12) screws marked [900O]. The PNL circuit board can then be removed. (Fig.4)

* *When the PNL circuit board is assembled, tighten the screws marked [900O] in the order of 1, 2 and the remaining screws. (Fig.4)*

< Bottom view >

1 - 2 : The order of the screw tightening




Fig.3

< Bottom view >

1 - 2 : The order of the screw tightening




Fig.4

5. Speaker (Woofer)**(Time required: About 8 minutes)**

5-1 Separate the bottom board assembly from the upper case assembly. (See procedure 1.)

5-2 Remove the four (4) screws marked [100]. The speaker (woofer) can then be removed. (Fig.5)

* *The woofers L and R can be removed in the same manner.*

6. GHL Keyboard Assembly**(Time required: About 12 minutes)**

6-1 Separate the upper case assembly from the bottom board assembly. (See procedure 1.)

6-2 Remove the MKO circuit board (holder). (See procedure 2.)

6-3 Remove the eight (8) screws marked [930A] and the eight (8) screws marked [920]. The GHL keyboard assembly can then be removed from the upper case assembly. (Fig.6)

6-4 When the GHL keyboard assembly is exchanged (not only removing), remove the two (2) screws marked [930B]. The reinforcing plate can then be removed from the GHL keyboard assembly. (Fig.6)

* *When the reinforcing plate is assembled, tighten the screws marked [930B] in the order of 1 and 2. (Fig.6)*

* *When the GHL keyboard assembly is assembled, tighten the screws marked [930A] in the order of 1, 2, 3 and the remaining screws. (Fig.6)*

< Top view >




Fig.5

< Bottom view >


**1 - 3 : The order of the screw tightening**

Fig.6

7. Disassembling the Keyboard Assembly

7-1 White key assembly and black key assembly

Remove the four (4) screws marked [270A] fixing a black key assembly and two (2) white key assemblies for one octave (C-B).

To remove the black and white key assemblies for one octave, grip and lift the both end lugs of white key, and then slide the black and white key assemblies toward you. (Fig.7, Fig.8)

- 7-2 When removing white keys numbered as A-1 and B-1 key and black key numbered as A#-1, remove two (2) screws marked [270B] and then lift the back of the keys and slide the black and white keys towards you. (Fig.7)

- 7-3 When removing the C7 key, remove a screw marked [270C] and then lift the back of C7 key and slide it towards you. (Fig.7)

* **When removing white key assembly and black key assembly, be careful not to allow grease to attach to the circuit board and rubber contacts, etc. (Fig.8)**




Fig.7




Fig.8




Fig.9

< Top View >




Fig.10

7-4 Actuate Rubber

Remove the actuate rubber. (Fig.9)

Notes: Note that the rubber contact has a specific installation direction.

One rubber contact fits for C#-C (for C-B keys).


7-5 Rubber Contact

Remove the black and white key assembly for two octaves related to the subject rubber contact. The rubber contact can then be removed. (Fig.10, Fig.11)

7-6 GHL88L Circuit Board

Remove the black and white key assembly (A-1-B2). (See procedure 7-1.)

Remove the six (6) screws marked [260A]. The GHL88L circuit board can then be removed. (Fig.10)



To remove the rubber contact for one octave, keys for 2 octaves need to be removed.

Fig.11

< Top View >





Fig.12

< Side View >



7-7 GHL88M Circuit Board

Remove the black and white key assembly (C2-B5).

(See procedure 7-1.)

Remove the seven (7) screws marked [260B]. The GHL88M circuit board can then be removed. (Fig.10)

Detach the filament tape and disconnect the FFC cable. (Fig.12)

7-8 GHL88H Circuit Board

Remove the black and white key assembly (C5-C7).

(See procedure 7-1.)

Remove the five (5) screws marked [260C]. The GHL88H circuit board can then be removed. (Fig.10)

< Rear View >




Fig.13

7-9 Hammer (White Key), (Black Key)

Remove the black and white key assembly for the related keys.

With the key frame placed upside down, push the hammer forward from the rear, then a click sound is heard and the hammer bearing section can be removed from the hammer axis of the key frame.

Take out the hammer sideways. (Fig.13, Fig.14)

Note: When removing the hammer, use care not to cause damage to the hammer bearing and its claw.




Fig.14

8. Assembling the Keyboard Assembly

8-1 Hammer (White Key), (Black Key)

After applying grease(G-1030Y) to the bearing section of the hammer, bring the hammer (white key)(black key) sideways from the rear, fit its bearing section to the hammer axis of the key frame and pull it forward until a click sound is heard. (Fig.15)

Note: There are 8 hammer types differing in weight. Be sure to check the type of the hammer for correct installation. (See Table 2)

< Rear View >




Fig.15

8-2 GHL88L Circuit Board

Tighten the six (6) screws marked [260A] to fix the GHL88L circuit boards. (Fig.10)

8-3 GHL88M Circuit Board

Connect the FFC cable to CN2 of the GHL88M circuit board, attach the filament tape. (Fig.12)

Pass the end of the cable into the through hole in the frame and pull it out from its outlet. (Fig.12)

Tighten the seven (7) screws marked [260B] to fix the GHL88M circuit board. (Fig.10)

Part Name		Range for Applicable Tone Keys	
White Key	Hammer W1	A-1	- F1
	Hammer W2	G1	- E3
	Hammer W3	F3	- D5
	Hammer W4	E5	- C7
Black Key	Hammer B1	A#-1	- F#1
	Hammer B2	G#1	- D#3
	Hammer B3	F#3	- C#5
	Hammer B4	D#5	- A#6

Table.2

*

Method of processing FFC cable

Pull the FFC cable not to touch to the key hammers by loosening of the cable under the circuit board, and fix the cable with the filament tape in such a state. (Photo1, Photo2) Then, wrap the cushion around the FFC cable. (Photo3) After you wrap the cushion around the FFC cable, do not put the filament tape directly to the cushion because it is too easy to peel it off. Therefore, put the filament tape directly to the FFC cable, not to the cushion. (Photo 4)



Photo.1




Photo.2




Photo.3




Photo.4

8-4 GHL88H Circuit Board

Tighten the five (5) screws marked [260C] to fix the GHL88H circuit board. (Fig.10)

8-5 Rubber Contact

Note that the rubber contact has a specific installation direction. Be careful not to install it in the wrong direction.

Note: A triangle mark ($\triangle$) on the rubber contact must face the front. (Fig.16)

To prevent looseness of the rubber contact, fit it securely in place using a clip or similar object. (Fig.17)

8-6 Actuate Rubber

After applying grease(G-1030Y) to top and bottom faces of the actuate rubber, fit it to the white key (black key). (Fig.18)

8-8 Use the two (2) screws marked [270B] to fix the A-1 to B-1 keys. (Fig.7)

8-9 Use a screw marked [270C] to fix the C7 key. (Fig.7)

8-7 White key assembly and black key assembly

After applying grease to the key guide, install the white key assembly/black key assembly.

At this time, check to make sure that the key guide of the key frame and inside slit at the front of white key as well as the contact arm of the hammer and actuate rubber of the white key assembly/black key assembly are installed properly. (Fig.19)

Use the four (4) screws marked [270A] to fix 1 octave white key assembly/black key assembly. (Fig.7)




Fig.16




Fig.17




Fig.18




Fig.19

■ LSI PIN DESCRIPTION

CONTENTS

• R8A02042BG (YC479A00) SWX08	22
• S1D13700F01A100 (X5422A00) LCD CONTROLLER	21
• μ PD789022GB-A15-8E (XZ56010R) CPU(MKS)	21
• YDA164C-QZE2 (YD652A00) AMP (POWER AMPLIFIER 20Wx2)	20

• YDA164C-QZE2 (YD652A00) AMP (POWER AMPLIFIER 20Wx2)

DM: IC035

PIN NO.	NAME	I/O	FUNCTION	PIN NO.	NAME	I/O	FUNCTION
1	AVSS	GND	Analog GND	17	HOPP	I	PWM Carrier Frequency Hopping setting pin
2	VREF	AO	Analog Reference Voltage Output	18	PLIMIT	I	Power Limit setting pin
3	REFA	AO	Internal Regulator Output	19	SLEEPN	I	Sleep Reset pin
4	DVDD	DVDD power	Digital Power	20	PROTN	O/D	Error Flag Output pin
5	MCK	I	Master Clock Input Pin	21	MUTEN	I	Mute pin
6	SDATA	I	Audio Data Input Pin	22	CKMOD	I	Clock Mode setting pin
7	SCLK	I	Bit Clock Input Pin	23	GAIN0	I	Gain setting pin 0
8	LRCLK	I	Word Clock Input Pin	24	GAIN1	I	Gain setting pin 1
9	DVSS	GND	Digital GND	25	MONO	I	Stereo/Mono setting pin
10	PVSSR	GND	GND for the digital amplifier output (Rch)	26	PVSSL	GND	GND for the digital amplifier output (Lch)
11	PVDDPR	PVDD power	Power for the digital amplifier output (Rch+)	27	PVDDML	PVDD power	Power for the digital amplifier output (Lch-)
12	OUTPR	O	Digital Amplifier Output (Rch+)	28	OUTML	O	Digital Amplifier Output (Lch-)
13	PVSSR	GND	GND for the digital amplifier output (Rch)	29	PVSSL	GND	GND for the digital amplifier output (Lch)
14	OUTMR	O	Digital Amplifier Output (Rch-)	30	OUTPL	O	Digital Amplifier Output (Lch+)
15	PVDDMR	PVDD power	Power for the digital amplifier output (Rch-)	31	PVDDPL	PVDD power	Power for the digital amplifier output (Lch+)
16	PVSSR	GND	GND for the digital amplifier output (Rch)	32	PVSSL	GND	GND for the digital amplifier output (Lch)

• μ PD789022GB-A15-8E (XZ56010R) CPU(MKS)

DM: IC012

PIN NO.	NAME	I/O	FUNCTION	PIN NO.	NAME	I/O	FUNCTION
1	P12	I/O	Port 1	23	P32/INTP2/CPT2	I/O	Port 3/External interrupt input/Capture edge input
2	P11	I/O		24	P31/INTP1	I/O	Port 3/External interrupt input
3	P10	I/O		25	P30/INTP0	I/O	
4	P47/KR7	I/O	Port 4/Key return signal detection input	26	P22/RXD/SIO	I/O	Port 2/Asynchronous serial interface serial data input/Serial interface serial data input
5	P46/KR6	I/O		27	P21/TXD/SO0	I/O	Port 2/Asynchronous serial interface serial data output/Serial interface serial data output
6	P45/KR5	I/O		28	P20/ASCK/ISCK0	I/O	Port 2/Asynchronous serial interface serial clock input/Serial interface serial clock
7	P44/KR4	I/O		29	P07	I/O	Port 0
8	P43/KR3	I/O		30	P06	I/O	
9	P42/KR2	I/O		31	P05	I/O	
10	P41/KR1	I/O		32	P04	I/O	
11	P40/KR0	I/O		33	P03	I/O	
12	NC			34	P02	I/O	
13	IC		Internally connected (N.C.)	35	P01	I/O	
14	X2		Clock	36	P00	I/O	
15	X1	I		37	NC		Power supply
16	VSS0		Ground	38	VDD1		
17	VDD0		Power supply	39	VSS1		Ground
18	/RESET	I	System reset	40	P17	I/O	Port 1
19	P53	I/O	Port 5	41	P16	I/O	
20	P52	I/O		42	P15	I/O	
21	P51/TO2	I/O	Port 5/16-bit timer output	43	P14	I/O	
22	P50/TIO/TO0	I/O	Port 5/External count clock input to 8-bit timer/8-bit timer output	44	P13	I/O	

• S1D13700F01A100 (X5422A00) LCD CONTROLLER

DM: IC006

PIN NO.	NAME	I/O	FUNCTION	PIN NO.	NAME	I/O	FUNCTION
1	VSS	—	Ground	33	VSS	—	Ground
2	AB12	I	Address bus	34	XCD1	O	Drain output
3	AB11	I		35	XCG1	I	Gate input
4	AB10	I		36	RESET#	I	Reset
5	AB9	I		37	SCANEN	I	Test mode set up input
6	AB8	I		38	TESTEN	I	
7	HIOVDD	—	Power supply	39	CLKI	I	Externally sourced system clock
8	AB7	I	Address bus	40	COREVDD	—	Power supply
9	AB6	I		41	RD#	I	Read strobe
10	AB5	I		42	WR#	I	Write strobe
11	AB4	I		43	CS#	I	Chip select
12	COREVDD	—	Power supply	44	DB7	I/O	Data bus
13	AB3	I	Address bus	45	DB6	I/O	
14	AB2	I		46	DB5	I/O	
15	AB1	I		47	DB4	I/O	Power supply
16	AB0	I		48	HIOVDD	—	
17	VSS	—	Ground	49	DB3	I/O	Data bus
18	FPDAT3	O	Data bus	50	DB2	I/O	
19	FPDAT2	O		51	DB1	I/O	
20	FPDAT1	O		52	DB0	I/O	Ground
21	FPDAT0	O		53	VSS	—	
22	NIOVDD	—	Power supply	54	WAIT#	O	Wait output
23	FPSHIFT	O	Shift clock	55	HIOVDD	—	Power supply
24	XECL	O	X driver enable chain clock	56	CNF0	I	Input pin for S1D 13700 setting
25	COREVDD	—	Power supply	57	CNF1	I	
26	FPLINE	O	Latch pulse	58	CNF2	I	
27	MOD	O	Frame signal	59	CNF3	I	
28	VSS	—	Ground	60	CNF4	I	Address strobe
29	YSCL	O	Scan shift clock	61	AS#	I	
30	FPFRAME	O	Scan start pulse	62	AB15	I	Address bus
31	YDIS	O	LCD power-down output	63	AB14	I	
32	NIOVDD	—	Power supply	64	AB13	I	

● R8A02042BG (YC479A00) SWX08

DM: IC023

PIN NO.	NAME	I/O	FUNCTION	PIN NO.	NAME	I/O	FUNCTION
A1	VSS	-	Ground (for I/O and for core)	E7	VSS	-	Ground (for I/O and for core)
A2	VSSADC	-	ADC analog ground	E8	VCCQ	-	The power supply +3.3V
A3	VCCADC	-	ADC analog power supply (Typ +3.3V)	E9	VSS	-	Ground (for I/O and for core)
A4	AN4	I(a)	ADC analog input 4	E10	VCCQ	-	The power supply +3.3V
A5	VREFADC	-	Analog module reference voltage. (Typ +3.3V)	E11	VCCQ	-	The power supply +3.3V
A6	SK1	Ish/O	External synchronous clock I/O 1	E12	VCCQ	-	The power supply +3.3V
A7	UCLK	I	USB external clock input (48MHz)	E13	VCCQ	-	The power supply +3.3V
A8	VSS	-	Ground (for I/O and for core)	E14	VSS	-	The power supply for internal cores(0V)
A9	FUNC_DM	I/O(a)	USB function data -	E15	VDD	-	The power supply +1.2V
A10	VSS	-	Ground (for I/O and for core)	E16	VDD	-	The power supply +1.2V
A11	HOST_DM	I/O(a)	USB host data - (After hard reset is released, it becomes Low output status.)	E17	VCCQ	-	The power supply +3.3V
A12	UCTL	I	USB output control (Make it to High when USB unused).	E18	VCCQ	-	The power supply +3.3V
A13	XTAL	O	Crystal oscillator output	E19	WE3NDQMUI/PH1	O	D31-D24 at byte writing of D31-D24 (active Low)/SDRAM is selected/port H 1
A14	EXTAL	I	Crystal oscillator input (16.9344MHz)	E20	A2	O	SH2A-CPU address bus 2
A15	VSS	-	Ground (for I/O and for core)	E21	D30/PF6	I/O	SH2A-CPU data bus 30/port PF 6
A16	CS4N/PH4	O	SH2A-CPU chip selection 4 (Low active)/port PH 4	E22	D29/PF5	I/O	SH2A-CPU data bus 29/port PF 5
A17	TRSTN	Ish	JTAG test reset input (Low active)	F1	MD5	I/O	Wave ROM, SDRAM data bus 5
A18	TDO	O	JTAG test data output	F2	MD4	I/O	Wave ROM, SDRAM data bus 4
A19	PA2	I/O	Parallel port A 2	F3	MD12	I/O	Wave ROM, SDRAM data bus 12
A20	PA0	I/O	Parallel port A 0	F4	MD11	I/O	Wave ROM, SDRAM data bus 11
A21	IRQ1	Ish	Interrupt input 1	F5	VDD	-	The power supply +1.2V
A22	VCCQ	-	The power supply +3.3V	F18	VDD	-	The power supply +1.2V
B1	MA1	O	Wave ROM, SDRAM address bus 1	F19	A3	O	SH2A-CPU address bus 3
B2	VSS	-	Ground (for I/O and for core)	F20	A4	O	SH2A-CPU address bus 4
B3	AN5	I(a)	ADC analog input 5	F21	D28/PF4	I/O	SH2A-CPU data bus 28/port PF 4
B4	AN2	I(a)	ADC analog input 2	F22	D27/PF3	I/O	SH2A-CPU data bus 27/port PF 3
B5	AN0	I(a)	ADC analog input 0	G1	MD7	I/O	Wave ROM, SDRAM data bus 7
B6	TxD1	O	Serial output 1	G2	MD6	I/O	Wave ROM, SDRAM data bus 6
B7	TxD0	O	Serial output 0	G3	MD14	I/O	Wave ROM, SDRAM data bus 14
B8	VSS	-	Ground (for I/O and for core)	G4	MD13	I/O	Wave ROM, SDRAM data bus 13
B9	FUNC_DP	I/O(a)	USB function data +	G5	VSS	-	Ground (for I/O and for core)
B10	VSS	-	Ground (for I/O and for core)	G18	VSS	-	Ground (for I/O and for core)
B11	HOST_DP	I/O(a)	USB host data + (After hard reset is released, it becomes Low output status.)	G19	A5	O	SH2A-CPU address bus 5
B12	SCL	Ish/OD	E bus (I2C) clock I/O (5V tolerant)	G20	A6	O	SH2A-CPU address bus 6
B13	CS0N	O	SH2A-CPU chip selection 0 (Low active)	G21	D26/PF2	I/O	SH2A-CPU data bus 26/port PF 2
B14	CS3N	O	SH2A-CPU chip selection 3 (Low active)	G22	D25/PF1	I/O	SH2A-CPU data bus 25/port PF 1
B15	CS6N/PH5	O	SH2A-CPU chip selection 6 (Low active)/port PH 5	H1	MA25/SCASN	O	Wave ROM, SDRAM address bus 25/CAS output for wave SDRAM (Low active)
B16	ASEBRKAKN	Ish/O	Emulator break (Low active)	H2	MA26/SCKE	O	Wave ROM, SDRAM address bus 26/Wave SDRAM clock is enable
B17	TMS	I	JTAG test mode selection input	H3	MA17/NFD1	O/I, I/O	Wave ROM, SDRAM address bus 17/Wave NAND flash data bus 1
B18	PA5	I/O	Parallel port A 5	H4	MD15	I/O	Wave ROM, SDRAM data bus 15
B19	PA1	I/O	Parallel port A 1	H5	VCCQ	-	The power supply +3.3V
B20	IRQ0	Ish	Interrupt input 0	H18	VCCQ	-	The power supply +3.3V
B21	VCCQ	-	The power supply +3.3V	H19	A7	O	SH2A-CPU address bus 7
B22	VDDPLL2	-	PLL1 analog power supply (Typ. +1.2V)	H20	A8	O	SH2A-CPU address bus 8
C1	MRDN/SDQM	O	Wave ROM enable read (Low active)/Waves SDRAM data is enable	H21	D24/PF0	I/O	SH2A-CPU data bus 24/port PF 0
C2	MCS0N	O	Wave ROM, SDRAM chip selection 0 (Low active)	H22	D23/PE7	I/O	SH2A-CPU data bus 23/port PE 7
C3	VSS	-	Ground (for I/O and for core)	J1	MA15	O	Wave ROM, SDRAM address bus 15/SDRAM bank selection 1)
C4	AN3	I(a)	ADC analog input 3	J2	MA16/NFD0	O/I, I/O	Wave ROM, SDRAM address bus 16/Wave NAND flash data bus 0
C5	AN1	I(a)	ADC analog input 1	J3	MA23/NFD7	O/I, I/O	Wave ROM, SDRAM address bus 23/Wave NAND flash data bus 7
C6	RxD1	Ish	Serial input 1	J4	MA24/SRASN	O	Wave ROM, SDRAM address bus 24/RAS output for wave SDRAM (Low active)
C7	RxD0	Ish	Serial input 0	J5	VSS	-	Ground (for I/O and for core)
C8	VSS	-	Ground (for I/O and for core)	J9	VSS	-	Ground (for I/O and for core)
C9	VBUS	I	USB cable connection monitor (5V tolerant)	J10	VSS	-	Ground (for I/O and for core)
C10	VSS	-	Ground (for I/O and for core)	J11	VSS	-	Ground (for I/O and for core)
C11	OVER_CURRENT_N	I	USB overcurrent detection (Low active) (5V tolerant)	J12	VSS	-	Ground (for I/O and for core)
C12	EICN	I	E bus reset output (Low active) (5V tolerant)	J13	VSS	-	Ground (for I/O and for core)
C13	CS1N/PH2	O	SH2A-CPU chip selection 1 (Low active)/port PH 2	J14	VSS	-	Ground (for I/O and for core)
C14	CS5N	O	SH2A-CPU chip selection 5 (Low active)	J18	VSS	-	Ground (for I/O and for core)
C15	ASEMDN	Ish	Debug mode setting (Low active)	J19	A9	O	SH2A-CPU address bus 9
C16	TDI	I	JTAG test data input	J20	A10	O	SH2A-CPU address bus 10
C17	PA7	I/O	Parallel port A 7	J21	D22/PE6	I/O	SH2A-CPU data bus 22/port PE 6
C18	PA4	I/O	Parallel port A 4	J22	D21/PE5	I/O	SH2A-CPU data bus 21/port PE 5
C19	WAITN	I	External wait input (Low active)	K1	MA11	O	Wave ROM, SDRAM address bus 11
C20	VCCQ	-	The power supply +3.3V	K2	MA12	O	Wave ROM, SDRAM address bus 12
C21	VSSPLL2	-	The power supply for SH2A PLL analog modules(0V)	K3	MA13	O	Wave ROM, SDRAM address bus 13/When 256Mbit SDRAM is connected, use it.)
C22	VDDPLL1	-	The Jlower supply for SH2A PLL. analog modules(1.2V)	K4	MA14	O	Wave ROM, SDRAM address bus 14/SDRAM bank selection 0)
D1	MD1	I/O	Wave ROM, SDRAM data bus 1	K5	VDD	-	The power supply +1.2V
D2	MD0	I/O	Wave ROM, SDRAM data bus 0	K9	VSS	-	Ground (for I/O and for core)
D3	MD8	I/O	Wave ROM, SDRAM data bus 8	K10	VSS	-	Ground (for I/O and for core)
D4	VSS	-	Ground (for I/O and for core)	K11	VSS	-	Ground (for I/O and for core)
D5	VDD	-	The power supply +1.2V	K12	VSS	-	Ground (for I/O and for core)
D6	VSS	-	Ground (for I/O and for core)	K13	VSS	-	Ground (for I/O and for core)
D7	RESN	Ish	Hardware reset (Low active)	K14	VSS	-	Ground (for I/O and for core)
D8	VCCQ	-	The power supply +3.3V	K18	VDD	-	The power supply +1.2V
D9	PULLUP_ENB	O	The USB pull-up is enable.	K19	A11	O	SH2A-CPU address bus 11
D10	VCCQ	-	The power supply +3.3V	K20	A12	O	SH2A-CPU address bus 12
D11	POWER_ENB	O	The USB voltage is enable.	K21	D20/PE4	I/O	SH2A-CPU data bus 20/port PE 4
D12	SDA	Ish/OD	E bus (I2C) data I/O (5V tolerant)	K22	D19/PE3	I/O	SH2A-CPU data bus 19/port PE 3
D13	CS2N/PH3	O	SH2A-CPU chip selection 2 (Low active)/port PH 3	L1	MA22/NFD6	O/I, I/O	Wave ROM, SDRAM address bus 22/Wave NAND flash data bus 6
D14	CS7N	O	SH2A-CPU chip selection 7 (Low active)	L2	MA21/NFD5	O/I, I/O	Wave ROM, SDRAM address bus 21/Wave NAND flash data bus 5
D15	TESTN	Ish	Test input (Low active)	L3	MA20/NFD4	O/I, I/O	Wave ROM, SDRAM address bus 20/Wave NAND flash data bus 4
D16	TCK	I	JTAG test clock input	L4	MA9	O	Wave ROM, SDRAM address bus 9
D17	PA6	I/O	Parallel port A 6	L5	MA10	O	Wave ROM, SDRAM address bus 10
D18	PA3	I/O	Parallel port A 3	L9	VSS	-	Ground (for I/O and for core)
D19	VCCQ	-	The power supply +3.3V	L10	VSS	-	Ground (for I/O and for core)
D20	A0	O	SH2A-CPU address bus 0	L11	VSS	-	Ground (for I/O and for core)
D21	VSSPLL1	-	PLL analog ground (0V)	L12	VSS	-	Ground (for I/O and for core)
D22	D31/PF7	I/O	SH2A-CPU data bus 31/port PF 7	L13	VSS	-	Ground (for I/O and for core)
E1	MD3	I/O	Wave ROM, SDRAM data bus 3	L14	VSS	-	Ground (for I/O and for core)
E2	MD2	I/O	Wave ROM, SDRAM data bus 2	L18	CKE	O	The clock is enable for SDRAM
E3	MD10	I/O	Wave ROM, SDRAM data bus 10	L19	A13	O	SH2A-CPU address bus 13
E4	MD9	I/O	Wave ROM, SDRAM data bus 9	L20	A14	O	SH2A-CPU address bus 14
E5	VSS	-	Ground (for I/O and for core)	L21	D18/PE2	I/O	SH2A-CPU data bus 18/port PE 2
E6	VDD	-	The power supply +1.2V	L22	D17/PE1	I/O	SH2A-CPU data bus 17/port PE 1

PIN NO.	NAME	I/O	FUNCTION	PIN NO.	NAME	I/O	FUNCTION
M1	MA19/NFD3	O/ I/O	Wave ROM, SDRAM address bus 19/Wave NAND flash data bus 3	V17	VDD	-	The power supply +1.2V
M2	MA18/NFD2	O/ I/O	Wave ROM, SDRAM address bus 18/Wave NAND flash data bus 2	V18	VCCQ	-	The power supply +3.3V
M3	MA8	O	Wave ROM, SDRAM address bus 8	V19	A24	O	SH2A-CPU address bus 24
M4	MA7	O	Wave ROM, SDRAM address bus 7	V20	A23	O	SH2A-CPU address bus 23
M5	MA6	O	Wave ROM, SDRAM address bus 6	V21	D5	I/O	SH2A-CPU data bus 5
M9	VSS	-	Ground (for I/O and for core)	V22	D6	I/O	SH2A-CPU data bus 6
M10	VSS	-	Ground (for I/O and for core)	W1	PB6	I/O	Parallel port B 6
M11	VSS	-	Ground (for I/O and for core)	W2	PB7	I/O	Parallel port B 7
M12	VSS	-	Ground (for I/O and for core)	W3	ED0/PC0	I/O	External CPU data bus 0/Port C 0
M13	VSS	-	Ground (for I/O and for core)	W4	VDD	-	The power supply +1.2V
M14	VSS	-	Ground (for I/O and for core)	W5	ED10/PD2	I/O	External CPU data bus 10/Port D 2
M18	A1	O	SH2A-CPU address bus 1	W6	ED14/PD6	I/O	External CPU data bus 14/Port D 6
M19	WE2N/DQMUL/PH0	O	D23-D16 at byte writing of D23-D16 (active Low)/SDRAM is selected/port H 0	W7	EA3/PK2	I/O	External CPU address bus 3/Port K 2
M20	CASLN	O	CAS output for SDRAM (Low active)	W8	RDQ1	I/O	SDRAM data bus 1 for DSP
M21	D16/PE0	I/O	SH2A-CPU data bus 16/port PE 0	W9	RDQ3	I/O	SDRAM data bus 3 for DSP
M22	VSS	-	The power supply for internal cores(0V)	W10	RDQ5	I/O	SDRAM data bus 5 for DSP
N1	MA5	O	Wave ROM, SDRAM address bus 5	W11	RDQ7	I/O	SDRAM data bus 7 for DSP
N2	MA4	O	Wave ROM, SDRAM address bus 4	W12	RRASN	O	RAS output of SDRAM for DSP (Low active)
N3	MA3	O	Wave ROM, SDRAM address bus 3	W13	RA11	O	SDRAM address bus 11 for DSP
N4	MA2	O	Wave ROM, SDRAM address bus 2	W14	RA2	O	SDRAM address bus 2 for DSP
N5	VDD	-	The power supply +1.2V	W15	RA4	O	SDRAM address bus 4 for DSP
N9	VSS	-	Ground (for I/O and for core)	W16	AUX1/DREQ3/PK7	I	AUX input/DMA forwarding demand input from external device to channel 3/Port K7
N10	VSS	-	Ground (for I/O and for core)	W17	SDIO/PK5	I	Serial audio input 0/port K5
N11	VSS	-	Ground (for I/O and for core)	W18	BW_MD0	I	Setting of width of SH2A-CPU data bus
N12	VSS	-	Ground (for I/O and for core)	W19	VCCQ	-	The power supply +3.3V
N13	VSS	-	Ground (for I/O and for core)	W20	A25	O	SH2A-CPU address bus 25
N14	VSS	-	Ground (for I/O and for core)	W21	D3	I/O	SH2A-CPU data bus 3
N18	VDD	-	The power supply +1.2V	W22	D4	I/O	SH2A-CPU data bus 4
N19	RASLN	O	RAS output for SDRAM (Low active)	Y1	ED1/PC1	I/O	External CPU data bus 1/Port C 1
N20	WE1N/DQMLU	O	D15-D8 at byte writing of D15-D8 (active Low)/SDRAM is selected	Y2	ED2/PC2	I/O	External CPU data bus 2/Port C 2
N21	D15	I/O	SH2A-CPU data bus 15	Y3	VDD	-	The power supply for internal cores(1.2V)
N22	CKIO	O	Clock output for SDRAM	Y4	ED7/PC7	I/O	External CPU data bus 7/Port C 7
P1	MWRN	O	Wave ROM, SDRAM write enable (Low active)	Y5	ED11/PD3	I/O	External CPU data bus 11/Port D 3
P2	MCS1N/PG0	O	Wave ROM, SDRAM chip selection 1 (Low active)/port G 0	Y6	ED15/PD7	I/O	External CPU data bus 15/Port D 7
P3	MCS3N/MA27/PG2	O	Wave ROM, SDRAM chip selection 3 (Low active)/Wave ROM address bus 27/port G 2	Y7	ERDN/PK3	I/O	External CPU lead is enable (Low active)/Port K 3
P4	BTCHG	Ish	Switch control of boot ROM	Y8	RDQ2	I/O	SDRAM data bus 2 for DSP
P5	VSS	-	Ground (for I/O and for core)	Y9	RDQ4	I/O	SDRAM data bus 4 for DSP
P9	VSS	-	Ground (for I/O and for core)	Y10	RDQ6	I/O	SDRAM data bus 6 for DSP
P10	VSS	-	Ground (for I/O and for core)	Y11	RWEN	O	WE output of SDRAM for DSP (Low active)
P11	VSS	-	Ground (for I/O and for core)	Y12	RCASN	O	CAS output of SDRAM for DSP (Low active)
P12	VSS	-	Ground (for I/O and for core)	Y13	RBS	O	SDRAM bank selection for DSP
P13	VSS	-	Ground (for I/O and for core)	Y14	RA1	O	SDRAM address bus 1 for DSP
P14	VSS	-	Ground (for I/O and for core)	Y15	RA3	O	SDRAM address bus 3 for DSP
P18	VSS	-	Ground (for I/O and for core)	Y16	DITO/PH7	O	Digital audio output/Port H7
P19	A16	O	SH2A-CPU address bus 16	Y17	SYI	Ish	Synchronous input from external device
P20	A15	O	SH2A-CPU address bus 15	Y18	SDI1/DREQ2/PK6	I	Synchronous input from external device
P21	D13	I/O	SH2A-CPU data bus 13	Y19	SDO0	O	Serial audio output 0
P22	D14	I/O	SH2A-CPU data bus 14	Y20	VCCQ	-	The power supply +3.3V
R1	MCS2N/MA28/PG1	O	Wave ROM, SDRAM chip selection 2 (Low active)/Wave ROM address bus 28/port G 1	Y21	D1	I/O	SH2A-CPU data bus 1
R2	NFCSEN	O	Wave NAND flash chip is enable (Low active)	Y22	D2	I/O	SH2A-CPU data bus 2
R3	NFRDY	I	Lady input for shape of waves NAND flash	AA1	ED3/PC3	I/O	External CPU data bus 3/Port C 3
R4	NFRDFB	Ish	Wave NAND flash data taking lead enable input	AA2	VDD	-	The power supply +1.2V
R5	VCCQ	-	The power supply +3.3V	AA3	ED5/PC5	I/O	External CPU data bus 5/Port C 5
R18	VCCQ	-	The power supply +3.3V	AA4	ED8/PD0	I/O	External CPU data bus 8/Port D 0
R19	A18	O	SH2A-CPU address bus 18	AA5	ED12/PD4	I/O	External CPU data bus 12/Port D 4
R20	A17	O	SH2A-CPU address bus 17	AA6	EA1/PK0	I/O	External CPU address bus 1/Port K 0
R21	D11	I/O	SH2A-CPU data bus 11	AA7	EWRN/PK4	I/O	External CPU light is enable (Low active)/Port K 4
R22	D12	I/O	SH2A-CPU data bus 12	AA8	RDQ15	I/O	SDRAM data bus 15 for DSP
T1	SCLK	O	Clock output for shape of waves SDRAM	AA9	RDQ13	I/O	SDRAM data bus 13 for DSP
T2	NFRDN/PG3	O	Wave NAND flash enable lead (Low active)/port G 3	AA10	RDQ11	I/O	SDRAM data bus 11 for DSP
T3	NFWEN/PG4	O	Wave NAND flash enable lead (Low active)/port G 4	AA11	RDQ9	I/O	SDRAM data bus 9 for DSP
T4	NFWPN/PG5	O	Wave NAND flashlight protecting (Low active)/port G 5	AA12	RCLK	O	SDRAM mask output for DSP
T5	VSS	-	The power supply for internal cores(0V)	AA13	RA12	O	SDRAM address bus 12 for DSP
T18	VSS	-	The power supply for internal cores(0V)	AA14	RA9	O	SDRAM address bus 9 for DSP
T19	A20	O	SH2A-CPU address bus 20	AA15	RA7	O	SDRAM address bus 7 for DSP
T20	A19	O	SH2A-CPU address bus 19	AA16	RA5	O	SDRAM address bus 5 for DSP
T21	D9	I/O	SH2A-CPU data bus 9	AA17	WCLK2/SDO3	O	Word clock output 2/Serial audio output 3
T22	D10	I/O	SH2A-CPU data bus 10	AA18	BCLK	O	Bit clock output (After hard reset is released, the H/L change is started)
U1	NFALE/PG6	O	Wave NAND flash address is enable/port G 6	AA19	SDO1	O	Serial audio output 1
U2	NFCLE/PG7	O	Wave NAND flash command is enable/port G 7	AA20	RDWRN	O	The SH2A-CPU lead light is enable
U3	PB0	I/O	Parallel port B 0	AA21	VCCQ	-	The power supply +3.3V
U4	PB1	I/O	Parallel port B 1	AA22	D0	I/O	SH2A-CPU data bus 0
U5	VDD	-	The power supply +1.2V	AB1	VDD	-	The power supply +1.2V
U18	VCCQ	-	The power supply +3.3V	AB2	ED4/PC4	I/O	External CPU data bus 4/Port C 4
U19	A22	O	SH2A-CPU address bus 22	AB3	ED6/PC6	I/O	External CPU data bus 6/Port C 6
U20	A21	O	SH2A-CPU address bus 21	AB4	ED9/PD1	I/O	External CPU data bus 9/Port D 1
U21	D7	I/O	SH2A-CPU data bus 7	AB5	ED13/PD5	I/O	External CPU data bus 13/Port D 5
U22	D8	I/O	SH2A-CPU data bus 8	AB6	EA2/PK1	I/O	External CPU address bus 2/Port K 1
V1	PB2	I/O	Parallel port B 2	AB7	ECSN	Ish	External CPU chip selection
V2	PB3	I/O	Parallel port B 3	AB8	RDQ14	I/O	SDRAM data bus 14 for DSP
V3	PB4	I/O	Parallel port B 4	AB9	RDQ12	I/O	SDRAM data bus 12 for DSP
V4	PB5	I/O	Parallel port B 5	AB10	RDQ10	I/O	SDRAM data bus 10 for DSP
V5	VDD	-	Parallel port B 5	AB11	RDQ8	I/O	SDRAM data bus 8 for DSP
V6	VDD	-	The power supply +1.2V	AB12	RDQM	O	SDRAM mask output for DSP
V7	VSS	-	Ground (for I/O and for core)	AB13	RA13	O	SDRAM address bus 13 for DSP
V8	RDQ0	I/O	SDRAM data bus 0 for DSP	AB14	RA10	O	SDRAM address bus 10 for DSP
V9	VSS	-	Ground (for I/O and for core)	AB15	RA8	O	SDRAM address bus 8 for DSP
V10	VCCQ	-	The power supply +3.3V	AB16	RA6	O	SDRAM address bus 6 for DSP
V11	VCCQ	-	The power supply +3.3V	AB17	SYSCCLK	O	System clock output (After hard reset is released, the H/L change is started)
V12	VCCQ	-	The power supply +3.3V	AB18	WCLK	O	Word clock output (After hard reset is released, the H/L change is started)
V13	VCCQ	-	The power supply +3.3V	AB19	'SYSCCLK2/SDO2/PH6'	O	System clock output 2: For T1 Co. DAC/Serial audio input 2/Port H 6
V14	VSS	-	Ground (for I/O and for core)	AB20	RDN	O	The SH2A-CPU lead is enable (Low active)
V15	VCCQ	-	The power supply +3.3V	AB21	'WEON/DQMLL'	O	D7-D0 at byte writing of D7-D0 (active Low)/SDRAM is selected
V16	CKOEN	I	Clock output control for SDRAM	AB22	VCCQ	-	The power supply +3.3V


■ **CIRCUIT BOARDS**

CONTENTS


- AJACK Circuit Board (YE942C0) 26
- DJACK Circuit Board (YE942C0)..... 26
- DM Circuit Board (YE941C0) 25
- ENC Circuit Board (YE943B0) 27
- GHL88H Circuit Board (X6246D0) 30
- GHL88L Circuit Board (X6244D0)..... 31
- GHL88M Circuit Board (X6245G0) 32
- MKO Circuit Board (YE943B0)..... 27
- MVR Circuit Board (YE943B0) 27
- PB Circuit Board (YE942C0) 27
- PEDAL Circuit Board (YE943B0) 27
- PNL Circuit Board (YE943B0) 28
- PNR Circuit Board (YE943B0) 29
- PWR Circuit Board (YE943B0) 27
- USB Circuit Board (YE942C0) 26

Note: See parts list for details of circuit board component parts.


- **DM Circuit Board**



Component Side




Pattern Side




- When 48P-TSOP is mounted to the location of IC007, its pin no.1 must be positioned to the pin no.3 of 56P-TSOP.

•AJACK Circuit Board




Component Side

•DJACK Circuit Board



Component Side


•USB Circuit Board




Component Side

AJACK : 2NA-ZE90110
 DJACK : 2NA-ZE90110
 USB : 2NA-ZE90110


•ENC Circuit Board




•MVR Circuit Board



•PWR Circuit Board




•PB Circuit Board



•MKO Circuit Board





•PEDAL Circuit Board




ENC	: 2NA-ZE90120	3
PWR	: 2NA-ZE90120	3
PEDAL	: 2NA-ZE90120	3
MVR	: 2NA-ZE90120	3
PB	: 2NA-ZE90110	2
MKO	: 2NA-ZE90120	3

•PNL Circuit Board





Component Side
2NA-ZE90120

•PNR Circuit Board





• GHL88H Circuit Board





Component Side

• GHL88L Circuit Board



Component Side

•GHL88M Circuit Board



Component Side

DM Circuit Board Test Method

The DM Circuit Board is provided with test points for service check purposes.

Check the test points on the DM Circuit Board if the following symptoms appear.

Symptoms and check items

- 1) No LCD display with Power SW ON --> Check items 1 to 5 sequentially
- 2) No sound or distorted sound --> Check items 1, 2 and 3, and OUTPUT check items.

Test Point

NO.	Test Point	Circuit	Judgment criteria	Measured by	Parts with possible defects
①	+B	Power supply for DM Circuit Board	More than 11.0V	Multimeter	FT01 or FZ1 (On AJACK Circuit Board)
②	+5D	5V power for digital circuit	5.0V±0.5V	Multimeter	IC020
③	+3.3D	3.3V power for digital circuit	3.3V±0.3V	Multimeter	IC019
④	+1.2D	1.2V power for digital circuit	1.2V±0.1V	Multimeter	IC017
⑤	RESET	CPU & memory reset signal	3.3V±0.3V	Multimeter	IC024
⑥	OUT-L	DAC output L channel	There shall be audio output without distortion.	Signal Checker	IC015
⑦	OUT-R	DAC output R channel	There shall be audio output without distortion.	Signal Checker	IC015


Note: Use the standard AC adapter PA-150 or PA-150A for check operation.

Output

NO.	SPEAKER OUTPUT	PHONES/OUTPUT	DAC-L/R TEST POINT	Parts with possible defects
1	×	×	×	IC023
2	×	×	○	IC023 or Error Detect
3	○	×	×	IC015
4	×	○	○	IC035
5	○	×	○	IC021 or HP Jack

Note: “○” mark expresses normalcy and “×” mark expresses a failed state.

DM Circuit Board (ZE901300)



Component Side

■ TEST PROGRAM

* *If you execute the test No.54 (Factory Set), then the user's preset data may be lost.
Therefore, backup the user's data in advance.*

A. PREPARATION


- 1) PA-150A or PA-150 (AC adaptor) is used.
- 2) Measuring device: Frequency counter, which can detect thousandth value or more, Level meter (with JIS-C filter), Oscilloscope
Note: Use a stereo plug and connect a load resistor of 33Ω to the [PHONES/OUTPUT] jack for measurement unless otherwise specified. Input impedance of the measuring device should be 1 M Ω or more.
- 3) Jigs: Pedal unit (LP-7A or LP-7AWH), Foot switch (FC-4 or FC-5), USB cable, USB flash memory, USB-MIDI driver (*1), PC (Install a USB-MIDI driver(*1) in PC and finish the THROUGH setup.)

*1: Obtain the USB-MIDI driver from Yamaha official website.

(URL>><http://www.yamaha.com/kbdapps/>)

B. HOW TO ENTER THE TEST PROGRAM

While pressing the C#2, F2 and G#2 keys, turn the [STANDBY/ON] switch on.



C. TEST PROCEDURE

- 1) When the test program is started, "TEST" will be displayed on the LCD.
- 2) Press the [-] or [+] button of the number buttons to select a test program item.
- 3) Press the [START/STOP] button to execute the test.

If the test result is OK, or the test item is completed, press the [START/STOP] button again to return to the test item selection display.

* Press the [-] or [+] button of the number buttons to select the next test program item.

* When the test result is OK, a plus sign (+) is added in front of its item name on display.

If the test result is NG, press the [DEMO/BGM] button or the lowest (leftmost) white key to return to the item selection display.

D. TEST PROGRAM LIST

TEST No.	LCD display	Test descriptions, Judging Criteria
1	001 Version	Displays version of the ROM. “*** Prog” “*** Wave” *** : Version
2	002 Memory Chk1 All	Checks the ROM, RAM, Wave ROM and Effect RAM connected to the CPU bus. If result is OK, Test No.3 to 7 test can be skipped. Confirm that “ Memory All OK ” is displayed on the LCD.
3	003 Rom Chk1	Checks the ROM connected to the CPU bus. Confirm that “ Rom OK ” is displayed on the LCD.
4	004 Ram Chk1	Checks the RAM connected to the CPU bus. Confirm that “ Ram OK ” is displayed on the LCD.
6	006 Wave Rom Chk1	Checks the Wave ROM connected to the CPU bus. Confirm that “ Wave Rom OK ” is displayed on the LCD.
7	007 Effect Ram Chk1	Checks the Effect RAM connected to the CPU bus. Confirm that “ Effect Ram OK ” is displayed on the LCD.
9	009 Pit Chk	Checks pitch accuracy. Connect the frequency counter to [PHONES/OUTPUT] jack. (Either L or R) Confirm that the correct signal is output. (441.0 Hz +/- 0.2 Hz)
10	010 Output R	Connect the level meter (with JIS-C filter) to the [PHONES/OUTPUT] jack. (33Ω load) Set the [MASTER VOLUME] control to the maximum position and check the output level. OUTPUT R: -12.0 +/- 2 dBu OUTPUT L: -60.0 dBu or less
11	011 Output L	Connect the level meter (with JIS-C filter) to the [PHONES/OUTPUT] jack. (33Ω load) Set the [MASTER VOLUME] control to the maximum position and check the output level. OUTPUT R: -60.0 dBu or less OUTPUT L: -12.0 +/- 2 dBu
16	016 SP Mute Chk	The C5 sound is played at L and R channels when the [START/STOP] button is pressed. Repeat the sound stop (MUTE ON) and the sound production (MUTE OFF) by pressing [+] or [-] button. Confirm that the sound stops at the speaker when MUTE ON. (The output of [PHONES/OUTPUT] jack does not stop.) * Do not insert any plugs to [PHONES/OUTPUT] jack.
17	017 Mute Chk	Connect the headphones to the [PHONES/OUTPUT] jack. The C5 sound is played at L and R channels when the [START/STOP] button is pressed. Repeat the sound stop (MUTE ON) and the sound production (MUTE OFF) by pressing [+] or [-] button. Confirm that the sound stops at both the speaker and the [PHONES/OUTPUT] jack, when MUTE ON. * Disconnect the headphones from [PHONES/OUTPUT] jack when check the speaker output.
18	018 HP Chk	“ HP In ” is displayed on the LCD when the [START/STOP] button is pressed. Connect the headphones to the [PHONES/OUTPUT] jack. Confirm that “ HP Out ” is displayed on the LCD. Disconnect the headphones from [PHONES/OUTPUT] jack. Confirm that “ HP OK ” is displayed on the LCD.
19	019 AUX-IN Chk	Confirm that “ Not Inserted ” is displayed when any plug is not inserted into the [AUX IN] jack. Confirm that “ Inserted ” is displayed when a plug is inserted into the [AUX IN] jack. (Loads: 33ohms to L ch and R ch) Input a sine wave (1 kHz, 0 dBu) into R ch of [AUX IN] terminal. (Do not input any signal into the L ch of [AUX IN] terminal.) Confirm that the output level at each terminal is as follows. OUTPUT R: -6.0 +/- 2 dBu OUTPUT L: -40.0 dBu or less Also, confirm that the output level at each terminal is reversed when L and R ch are reversely inputted.

TEST No.	LCD display	Test descriptions, Judging Criteria
21	021 SW Chk	Checks the switches on the panel. Press the switches as shown in the LCD. When a switch is pressed, a sound is played at the prescribed pitch. (Refer to the switch test item list on the p.38) Also, check that no key stick is existed. Confirm that “SW OK” is displayed on the LCD when all the switches are pressed as indicated. If more than two switches are pressed at a time, “Over Two” is displayed. Confirm that the rotary encoder is clockwise set to UP and is counterclockwise set to DOWN. To cancel the running test, press the [DEMO/BGM] button or the lowest key (white key C1) to return to the item selection display.
22	022 All LED Chk	Confirm that all LEDs turned on.
23	023 Red LED Chk	Confirm that all Red LEDs turned on.
24	024 Green LED Chk	Confirm that all Green LEDs turned on.
25	025 LCD On	Confirm that all the dots on the LCD are turned on.
26	026 LCD Off	Confirm that all the dots on the LCD are turned off.
27	027 LCD Contrast Chk	Checks the contrast of the LCD. Confirm that the LCD becomes blue (or white) when the contrast knob is turned clockwise (or counterclockwise). Adjust the contrast knob to the legible position of LCD.
29	029 Master Vol Chk	Set the main volume to the minimum position first, and move it to the maximum position. Confirm that “Master Vol OK” is displayed on the LCD.
30	030 Emergency Circuit Chk	The A3 sound is played at L and R channels when the [START/STOP] button is pressed. Repeat the sound stop (Emergency Circuit ON) and the sound production (Emergency Circuit OFF) by pressing [+] or [-] button. Confirm that the sound stops at both the speaker and the [PHONES/OUTPUT] jack, when Emergency Circuit ON. If the failure detection system is not detected, “Emergency Circuit NG” is displayed. * Disconnect the headphones from [PHONES/OUTPUT] jack, when check the speaker output.
31	031 Pedal1 Chk	Before power switch ON, Connect the pedal unit (LP-7A etc.) to the [PEDAL UNIT] jack. The C3 sound is played when the [START/STOP] button is pressed with the pedal released. The C4 sound is played when the soft (left) pedal is depressed. Released the pedal again and the sound will be stopped. Confirm that “Pedal1 OK” is displayed on the LCD.
32	032 Pedal2 Chk	Before power switch ON, Connect the pedal unit (LP-7A etc.) to the [PEDAL UNIT] jack. The C3 sound is played when the [START/STOP] button is pressed with the pedal released. The C4 sound is played when the sostenuto (center) pedal is depressed. Released the pedal again and the sound will be stopped. Confirm that “Pedal2 OK” is displayed on the LCD.
33	033 Pedal3 Chk	Before power switch ON, Connect the pedal unit (LP-7A etc.) to the [PEDAL UNIT] jack. The C3 sound is played when the [START/STOP] button is pressed with the pedal released. The G4 sound is played when the damper (right) pedal is pressed until the half position, and the C4 sound is played when the pedal is depressed fully. Released the pedal again and the sound will be stopped. Confirm that “Pedal3 OK” is displayed on the LCD.

TEST No.	LCD display	Test descriptions, Judging Criteria
34	034 Pedal4 Chk	Before power switch ON, Connect the foot switch (FC-4 or FC-5) to the [SUSTAIN] jack. The C3 sound is played when the [START/STOP] button is pressed with the pedal released. The C4 sound is played when the pedal is depressed. Released the pedal again and the sound will be stopped. Confirm that "Pedal4 OK" is displayed on the LCD.
35	035 Pitch Bend Chk	Confirm the position of the wheel is center. The G3 sound is played when the [PITCH BEND] wheel is rotated to maximum position and the C3 sound is played when the wheel is rotated to minimum position. The C4 sound is played when the wheel is returned center position. Confirm that "Pitch Bend OK" is displayed on the LCD.
37	037 MIDI Chk	Connect the PC with a USB-MIDI driver installed and the [USB TO HOST] terminal using a USB cable, and execute the test. (As for the PC, install a USB-MIDI driver in the PC and finish the THROUGH setup, in advance.) Confirm that the C4 sound is played and the LCD displays "MIDI OK" .
38	038 USB Connect Chk	1. "USB Connect1 --" is displayed on the LCD when the [START/STOP] button is pressed. Connect the [USB TO DEVICE] and [USB TO HOST] terminals using the USB cable. Confirm that "USB Connect2 --" is displayed on the LCD. 2. Remove the USB cable from the [USB TO DEVICE] terminal, and insert a USB flash memory into the [USB TO DEVICE] terminal. Confirm that the C4 sound is played and the LCD displays "USB Connect OK" .
39	039 USB Strage Chk	Connect a USB flash memory to the [USB TO DEVICE] terminal, and execute the test. (The USB memory must be formatted by the instrument.) Confirm that "USB Storage OK" is displayed on the LCD. In case of NG, the following message is displayed. "USB Storage NG" : Failure in reading/writing "NO Storage" : No media "PROTECT" : Protected media
49	049 Rom Chk2	Checks the ROM connected to the CPU bus. (Full address) Confirm that "Rom OK" is displayed on the LCD. It will take about 60 seconds for the check.
50	050 Ram Chk2	Checks the RAM connected to the CPU bus. (Full address) Confirm that "Ram OK" is displayed on the LCD.
52	052 Wave Rom Chk2	Checks the Wave ROM connected to the CPU bus. (Full address) Confirm that "Wave Rom OK" is displayed on the LCD. It will take about 60 seconds for the check.
53	053 Effect Ram Chk2	Checks the Effect RAM connected to the CPU bus. (Full address) Confirm that "Effect Ram OK" is displayed on the LCD. It will take about 30 seconds for the check.
54	054 Factory Set	Initializes the entire backup area to reset to the factory default. "Factory Set --" is displayed on the LCD during the factory set. "Factory Set End" is displayed on the LCD when the factory set is finished. Do not turn off the power during this process.
55	055 Test Exit	This will leave the test program, reset the system and change to the play mode. Do not turn off the power until the main screen is displayed.

• Other Tests

Noise Level Check

Connect the level meter (with JIS-C filter) to the L/R of the [PHONES/OUTPUT] jack. (33 Ω load)

Set the [MASTER VOLUME] to the maximum level and check the noise level. Do not insert any plugs to [AUX IN] jack.

· PHONES L, R: -90 dBu or less

Switch test item list

Order	Switch Name	LCD Display	Note No.
1	DATA ENTRY +	Dial Up	C2
2	DATA ENTRY -	Dial Down	C#2
3	DEMO/BGM	Demo	D2
4	SCORE	Score	D#2
5	LYRICS	Lyrics	E2
6	REC	Song REC	F2
7	WAITING	Lesson Waiting	F#2
8	YOUR TEMPO	Lesson YourTmp	G2
9	MINUS ONE	Lesson MinusOne	G#2
10	SMART CHORD	Smart Chord	A2
11	STYLE RECOMMENDER	Style Recommend	A#2
12	R/1	Song 1	B2
13	L/2	Song 2	C3
14	3	Song 3	C#3
15	4	Song 4	D3
16	5	Song 5	D#3
17	A	Song A	E3
18	METRONOME ON/OFF	Metronome	F3
19	TEMPO/TAP	Tempo/TAP	F#3
20	ACMP ON/OFF	ACMP	G3
21	INTRO/ENDING/rit	Intro	G#3
22	MAIN/AUTO FILL	Main/Fill	A3
23	SYNC STOP	Sync Stop	A#3
24	SYNC START	Sync Start	B3
25	START STOP	Start/Stop	C4
26	BANK	Memory	C#4
27	REGIST MEMORY 1	Regist 1	D4
28	REGIST MEMORY 2	Regist 2	D#4
29	REGIST MEMORY 3	Regist 3	E4
30	REGIST MEMORY 4	Regist 4	F4
31	CATEGORY <<	Category -	F#4
32	CATEGORY >>	Category +	G4
33	EXIT	Exit	G#4
34	EXECUTE	Execute	A4
35	PORTABLE GRAND	Portable Grand	A#4
36	SONG	Song	B4
37	STYLE	Style	C5
38	VOICE	Voice	C#5
39	MUSIC DATABASE	MusicDataBase	D5
40	Tenkey 1	Tenkey 1	D#5
41	Tenkey 2	Tenkey 2	E5
42	Tenkey 3	Tenkey 3	F5
43	Tenkey 4	Tenkey 4	F#5
44	Tenkey 5	Tenkey 5	G5
45	Tenkey 6	Tenkey 6	G#5
46	Tenkey 7	Tenkey 7	A5
47	Tenkey 8	Tenkey 8	A#5
48	Tenkey 9	Tenkey 9	B5
49	Tenkey -	Tenkey -	C6
50	Tenkey 0	Tenkey 0	C#6
51	Tenkey +	Tenkey +	D6
52	FILE CONTROL	File Menu	D#6
53	FUNCTION	Function	E6
54	SPLIT ON/OFF	Split	F6
55	DUAL ON/OFF	Dual	F#6
56	HARMONY ON/OFF	Harmony	G6

■ BACKUP

The following data will be always maintained even if the power is turned off.

If you want to initialize backup data, use the "Clearing Backup data" operation of "INITIALIZATION" as explained below.

The "Clearing Backup data" does not delete the files that have been transferred from a computer or loaded from a USB flash memory.

If you want to delete the all files, see "Clearing files in flash memory area" below.

● Backup Data

- Registration Memory data
- Function Settings: Tuning, Split Point, Touch Sensitivity, Style Volume, Song Volume, Metronome Volume, Grade, Demo Group, Demo Play mode, Demo Cancel, Panel Sustain, Master EQ type, Chord Fingering, Auto Power Off setting, Damper Resonance ON/OFF, Output Gain, I.A. Control ON/OFF, I.A. Control Depth, Audio Volume, Aux IN Level

In addition to the Backup data above, all the User Songs and all the Song and Style files transferred from a computer or loaded from a USB flash memory will be maintained even if you turn off the power.

■ INITIALIZATION


This function erases the Backup data described above and Song/Style data, then restores all the default factory settings.

As required, execute one of the following two procedures.

• Clearing Backup data

This operation initializes the backup data.

Turn the power on by pressing the [⏻] (Standby/On) switch while holding the highest white key on the keyboard.




• Clearing files in flash memory area

This operation deletes all User Songs and all the Songs and Styles that have been transferred from a computer or loaded from a USB flash memory. Turn the power on by pressing the [⏻] (Standby/On) switch while simultaneously holding the highest white key and the three highest black keys on the keyboard.



When you "Clearing files in flash memory area", Song data and Style data you have purchased and downloaded will also be cleared. Make sure to save your important data by transferring to a computer.

SYSTEM BOOTING FLOW CHART



* "Factory Set executed" refers to the condition of turning on the power after executing "Factory Set" in the Test Program.

* As for the fail safe circuit check, it checks whether the mute functions correctly when the pulse ERR-DETECT is interrupted.

PortableGrand

DGX-650B/DGX-650WH

PARTS LIST

■ CONTENTS

OVERALL ASSEMBLY	2
MAIN UNIT	4
UPPER CASE ASSEMBLY	8
BOTTOM BOARD ASSEMBLY.....	9
KEYBOARD ASSEMBLY.....	10
FOOT PEDAL.....	12
ELECTRICAL PARTS.....	13
OPTIONAL PARTS	
• PEDAL UNIT (LP-7A/LP-7AWH)	23

Note) DESTINATION ABBREVIATIONS



A: Australian model	O: Chinese model
B: British model	Q: South-east Asia model
C: Canadian model	T: Taiwan model
D: German model	U: U.S.A. model
E: European model	V: General export model (110V)
F: French model	W: General export model (220V)
H: North European model	N,X: General export model
I: Indonesian model	Y: Export model
J: Japanese model	K: Korean model
M: South African model	P: Brazilian model

■ WARNING


Components having special characteristics are marked  and must be replaced with parts having specifications equal to those originally installed.

- The numbers in "QTY" shows quantities for each unit.
- The parts with "--" in "Part No." are not available as spare parts.
- This mark "}" in the REMARKS column means these parts are interchangeable.
- The second letter of the shaded () part number is I, not one.
- The second letter of the shaded () part number is O, not zero.


OVERALL ASSEMBLY



Foot Pedal (See page 12.)



AC Adaptor



REF NO.	PART NO.	DESCRIPTION	部 品 名	REMARKS	QTY	RANK
10	--	OVERALL ASSEMBLY	総 組 立	DGX-650B/DGX-650WH		
10	--	MAIN UNIT	メ イ ン ユ ニ ッ ト	DGX-650B (ZF00830)		
* 20	ZF493900	SIDE BOARD L ASSEMBLY	側 板 L A s s ' y	DGX-650B (ZF00840)		
* 20	ZF494100	SIDE BOARD L ASSEMBLY	側 板 L A s s ' y	DGX-650WH		
20a	--	SIDE BOARD L	側 板	L DGX-650B (ZF35310)		
20a	--	SIDE BOARD L	側 板	L DGX-650WH (ZF35320)		
20b	--	SIDE BOARD PLATE F	側 板 金 具	F DGX-650B (ZF38310)		
20b	--	SIDE BOARD PLATE F	側 板 金 具	F DGX-650WH (ZF38330)		
20c	--	SIDE BOARD PLATE R	側 板 金 具	R DGX-650B (ZF38320)		
20c	--	SIDE BOARD PLATE R	側 板 金 具	R DGX-650WH (ZF38340)		
20d	WE95510R	BIND HEAD TAPPING SCREW-1	T P # 1 + B I N D	DGX-650B	6	01
20d	WE97070R	BIND HEAD TAPPING SCREW-1	T P # 1 + B I N D	DGX-650WH	6	01
20e	WK844500	CAP BLACK	キャ ッ プ ブ ラ ッ ク	DGX-650B	4	01
20e	WK844400	CAP GRAY	キャ ッ プ グ レ ー	DGX-650WH	4	01
* 30	ZF494000	SIDE BOARD R ASSEMBLY	側 板 R A s s ' y	DGX-650B		
* 30	ZF494200	SIDE BOARD R ASSEMBLY	側 板 R A s s ' y	DGX-650WH		
30a	--	SIDE BOARD R	側 板	R DGX-650B (ZF35330)		
30a	--	SIDE BOARD R	側 板	R DGX-650WH (ZF35340)		
30b	--	SIDE BOARD PLATE F	側 板 金 具	F DGX-650B (ZF38310)		
30b	--	SIDE BOARD PLATE F	側 板 金 具	F DGX-650WH (ZF38330)		
30c	--	SIDE BOARD PLATE R	側 板 金 具	R DGX-650B (ZF38320)		
30c	--	SIDE BOARD PLATE R	側 板 金 具	R DGX-650WH (ZF38340)		
30d	WE95510R	BIND HEAD TAPPING SCREW-1	T P # 1 + B I N D	DGX-650B	6	01
30d	WE97070R	BIND HEAD TAPPING SCREW-1	T P # 1 + B I N D	DGX-650WH	6	01
30e	WK844500	CAP BLACK	キャ ッ プ ブ ラ ッ ク	DGX-650B	4	01
30e	WK844400	CAP GRAY	キャ ッ プ グ レ ー	DGX-650WH	4	01
* 40	ZF494500	STAND RAIL ASSEMBLY	框 A s s ' y	DGX-650B		
* 40	ZF494600	STAND RAIL ASSEMBLY	框 A s s ' y	DGX-650WH		
40a	--	STAND RAIL	ス タ ン ド 框	DGX-650B (ZF35370)		
40a	--	STAND RAIL	ス タ ン ド 框	DGX-650WH (ZF35380)		
40b	--	ANGLE BRACKET	框 補 強 金 具	DGX-650B (WA69460)	2	
40b	--	ANGLE BRACKET	框 補 強 金 具	DGX-650WH (WA69480)	2	
40c	WE95510R	BIND HEAD TAPPING SCREW-1	T P # 1 + B I N D	DGX-650B	8	01
40c	WE97070R	BIND HEAD TAPPING SCREW-1	T P # 1 + B I N D	DGX-650WH	8	01
50	WT984310	TOE BLOCK BAG UP	妻 土 台 袋 入	DGX-650B		
50	ZF494900	TOE BLOCK BAG UP	妻 土 台 袋 入	DGX-650WH		
50a	--	TOE BLOCK L	妻 土 台 L	DGX-650B (WT78830)		
50a	--	TOE BLOCK L	妻 土 台 L	DGX-650WH (ZF10540)		
50b	--	TOE BLOCK R	妻 土 台 R	DGX-650B (WT78840)		
50b	--	TOE BLOCK R	妻 土 台 R	DGX-650WH (ZF10550)		
60	ZF495200	SCREW SET	ネ ジ セ ッ ト	DGX-650B		
60	ZF495300	SCREW SET	ネ ジ セ ッ ト	DGX-650WH		
60a	--	JOINT CONNECTOR	ナ ッ ト 特 殊	(WF55910)	4	
60b	--	BIND HEAD SCREW	小 ネ ジ + B I N D	DGX-650B (WE98360)	12	
60b	--	BIND HEAD SCREW	小 ネ ジ + B I N D	DGX-650WH (WE98720)	12	
60c	--	TRUSS HEAD SCREW	特 注 ネ ジ + T R U S	(WF49230)	4	
60d	--	TRUSS HEAD SCREW	特 注 ネ ジ + T R U S	(WH28700)	4	
60d	--	TRUSS HEAD SCREW	特 注 ネ ジ + T R U S	DGX-650WH (WF05290)	4	
60e	--	TRUSS HEAD SCREW	小 ネ ジ + T R U S	(WF49240)	4	
* 70	ZF501100	STAY SET	金 具 セ ッ ト	DGX-650B		
* 70	ZF501200	STAY SET	金 具 セ ッ ト	DGX-650WH		
70a	--	ST CATCH ANGLE L	S T 受 け 金 具	L DGX-650B (ZF38220)		
70a	--	ST CATCH ANGLE L	S T 受 け 金 具	L DGX-650WH (ZF38240)		
70b	--	ST CATCH ANGLE R	S T 受 け 金 具	R DGX-650B (ZF38230)		
70b	--	ST CATCH ANGLE R	S T 受 け 金 具	R DGX-650WH (ZF38250)		
70c	--	STAND ANGLE	ス タ ン ド ア ン グ ル	DGX-650B (ZF38100)	2	
70c	--	STAND ANGLE	ス タ ン ド ア ン グ ル	DGX-650WH (ZF38110)	2	
		ACCESSORIES	付 属 品	DGX-650B/DGX-650WH		
* ZF451800		MUSIC REST WITH BAG	譜 面 板 袋 入 り	DGX-650B		
* ZF451900		MUSIC REST WITH BAG	譜 面 板 袋 入 り	DGX-650WH		
WU089600		FOOT PEDAL	フ ッ ト ペ ダ ル		10	
WK014700		AC ADAPTOR	A C ア ダ プ タ ー	U,C	08	
WR527000		AC ADAPTOR	A C ア ダ プ タ ー	E,I	10	
WR527100		AC ADAPTOR	A C ア ダ プ タ ー	B	11	
WR527200		AC ADAPTOR	A C ア ダ プ タ ー	DGX-650B O		
WU356400		AC ADOPOTR	A C ア ダ プ タ ー	K		
* ZF498400		CHINESE SHEET SET	中 文 シ ー ト 袋 入 り	DGX-650B O	08	


*: New Parts

RANK : Japan only




■ MAIN UNIT


• Bottom view 1




• Bottom view 2




• Rear view




• Bottom view 3




• Bottom view 4



• Bottom view 5



• Top view



DGX-650B/DGX-650WH

REF NO.	PART NO.	DESCRIPTION		部 品 名	REMARKS	QTY	RANK
	--	MAIN UNIT		メ イ ン ユ ニ ッ ト	DGX-650B/DGX-650WH		
	--	MAIN UNIT		メ イ ン ユ ニ ッ ト	DGX-650B (ZF00830)		
	--	MAIN UNIT		メ イ ン ユ ニ ッ ト	DGX-650WH (ZF00840)		
* 10	ZF008500	UPPER CASE ASSEMBLY		上 ケ ー ス A s s ' y	DGX-650B		
* 10	ZF008600	UPPER CASE ASSEMBLY		上 ケ ー ス A s s ' y	DGX-650WH		
* 20	ZF009000	BOTTOM BOARD ASSEMBLY		底 板 A s s ' y			
* 30	ZF009200	PN_SWITCH A		P N ス イ ッ チ A	DEMO/BGM, REC	2	
* 40	ZF009300	PN_SWITCH B		P N ス イ ッ チ B	SCORE, LYRICS, SMART CHORD, STYLE RECOMMENDER		
* 50	ZF009400	PN_SWITCH C		P N ス イ ッ チ C	WAITING, YOUR TEMPO, MINUS ONE		
* 60	ZF010500	PN_SWITCH D PRINTED		P N ス イ ッ チ D 印 刷 品	R/1, L/2, 3, 4, 5, A		
* 70	ZF009600	PN_SWITCH E		P N ス イ ッ チ E	METRONOME ON/OFF, TEMPO/TAP, REPEAT&LEARN, A-B REPEAT, REW, FF, PAUSE, START/STOP		
* 80	ZF009700	PN_SWITCH F		P N ス イ ッ チ F	REGIST MEMORY BANK, 1-4		
* 90	ZF010600	PN_SWITCH G PRINTED		P N ス イ ッ チ G 印 刷 品	CATEGORY(<<, >>)		
* 100	ZF009900	PN_SWITCH H		P N ス イ ッ チ H	EXIT, EXECUTE		
* 110	ZF010000	PN_SWITCH I		P N ス イ ッ チ I	PORTABLE GRAND, SONG/AUDIO, STYLE, VOICE, MUSIC DATABASE		
* 120	ZF010700	PN_SWITCH J PRINTED		P N ス イ ッ チ J 印 刷 品	0-9, -/NO, +/YES		
* 130	ZF010200	PN_SWITCH K		P N ス イ ッ チ K	SPLIT ON/OFF, DUAL ON/OFF, HARMONY ON/OFF		
* 140	ZF010300	PN_SWITCH L		P N ス イ ッ チ L	FILE CONTROL, FUNCTION		
* 150	ZE901500	CIRCUIT BOARD	PNL	P N L シ ー ト			
* 160	ZE901700	CIRCUIT BOARD	PNR	P N R シ ー ト			
* 170	WJ584000	ENCODER KNOB	BLACK	エ ン コ ー ダ ツ マ ミ	DGX-650B DATA ENTRY	04	
* 170	V8866501	ENCODER KNOB	GRAY	エ ン コ ー ダ ツ マ ミ	DGX-650WH DATA ENTRY	01	
* 180	ZE901800	CIRCUIT BOARD	AJACK	A J A C K シ ー ト			
* 190	ZE901300	CIRCUIT BOARD	DM	D M シ ー ト			
* 200	ZE901400	CIRCUIT BOARD	DJACK	D J A C K シ ー ト			
* 210	ZE901900	CIRCUIT BOARD	PEDAL	P E D A L シ ー ト			
* 220	WT983000	NONWOVEN CLOTH		不 織 布			
* 230	ZE902200	CIRCUIT BOARD	MVR	M V R シ ー ト			
* 240	VU43240R	V-KNOB	BLACK	V ツ マ ミ	DGX-650B MASTER VOLUME	01	
* 240	V836130R	V-KNOB	GRAY	V ツ マ ミ	DGX-650WH MASTER VOLUME	01	
* 250	ZE902100	CIRCUIT BOARD	PWR	P W R シ ー ト			
* 260	V715120R	PUSH KNOB BLACK		プ ッ シ ュ ツ マ ミ ク ロ	STANDBY/ON	01	
* 270	ZE902000	CIRCUIT BOARD	USB	U S B シ ー ト			
* 280	WT788700	BRACKET		ブ ラ ケ ッ ト			
* 290	ZE902800	CIRCUIT BOARD	PB	P B シ ー ト			
* 300	VY79310R	WHEEL ASSEMBLY		ホ イ ー ル A s s ' y		04	
300a	--	WHEEL		ホ イ ー ル	PITCH BEND (VY75080)		
300b	--	SPRING		ホ イ ー ル バ ネ	(VT44010)		
* 310	--	GREASE PK G31KA (1KG)	G-31KA	グ リ ー ス	(VE96850)	2	
* 330	YF221A00	LOUD SPEAKER	5.0cm 6ohm 10W	ス ピ ー カ	Tweeter		
* 370	--	CIRCUIT BOARD	MKO	M K O シ ー ト	(ZE90270)		
* 380	--	LCD ASSEMBLY		液 晶 A s s ' y	(WT98310)		
* 390	ZC589700	GHL KEYBOARD TEXTURE	A88 K6	G H L 鍵 盤 黒 シ ボ D		04	
* 410	ZG884900	LOWER CASE F MOLDING		下 ケ ー ス F 成 形 品	DGX-650B		
* 410	ZG914600	LOWER CASE F MOLDING		下 ケ ー ス F 成 形 品	DGX-650WH		
* 420	ZF013900	LOWER CASE L MOLDING		下 ケ ー ス L 成 形 品	DGX-650B		
* 420	ZF014000	LOWER CASE L MOLDING		下 ケ ー ス L 成 形 品	DGX-650WH		
* 430	ZF014100	LOWER CASE R MOLDING		下 ケ ー ス R 成 形 品	DGX-650B		
* 430	ZF014200	LOWER CASE R MOLDING		下 ケ ー ス R 成 形 品	DGX-650WH		
* 440	V928180R	FOOT	T1.6	ゴ ム 脚		4	01
* 450	WT983300	CUSHION	730X17X2	ク ッ シ ョ ン		3	
* 460	--	REINFORCING PLATE	2.0	補 強 シ ー ト	(WU17490)		
* 500	--	CLIP, WIRE		束 線 止 め	(CB81751)		
* 510	--	CORD BINDER	S-72B	束 線 止 め	(WD79640)	4	
* 520	--	CORD CLAMPER		束 線 止 め	(CB83620)	2	
* 540	--	FILAMENT TAPE	12X50	粘 着 テ ー プ	(VA12610)	2	
* 600	ZF629300	FFC CABLE	12P 80MM P=1.0	F F C ケ ー ブ ル			
* 620	ZF509100	FFC CABLE	DJK 5P 130MM P=1.0	D J K 束 線			
* 630	ZF629400	FFC CABLE	15P 90MM P=1.0	F F C ケ ー ブ ル			
* 640	ZF629600	FFC CABLE	18P 90MM P=1.0	F F C ケ ー ブ ル			
* 650	ZF508900	FFC CABLE	PDN 5P 90MM P=1.0	P D N 束 線			
* 660	--	CONNECTOR ASSEMBLY	USB	U S B 束 線	(ZF86850)		

* : New Parts


RANK : Japan only

[illegible]

* : New Parts

RANK : Japan only

■ UPPER CASE ASSEMBLY




REF NO.	PART NO.	DESCRIPTION	部 品 名	REMARKS	QTY	RANK
*		UPPER CASE ASSEMBLY	上 ケ ー ス A s s ' y	DGX-650B/DGX-650WH		
*	ZF008500	UPPER CASE ASSEMBLY	上 ケ ー ス A s s ' y	DGX-650B		
*	ZF008600	UPPER CASE ASSEMBLY	上 ケ ー ス A s s ' y	DGX-650WH		
10	--	UPPER CASE PRINTED	上 ケ ー ス 印 刷 品	DGX-650B (ZF01430)		
10	--	UPPER CASE PRINTED	上 ケ ー ス 印 刷 品	DGX-650WH (ZF01440)		
*	20	SP GRILLE PAINTED	S P グ リ ル 塗 装 品	DGX-650B	2	
*	20	SP GRILLE PAINTED	S P グ リ ル 塗 装 品	DGX-650WH	2	
*	30	ZF014700 KEY BLOCK L	拍 子 木 L	DGX-650B		
*	30	ZF014800 KEY BLOCK L	拍 子 木 L	DGX-650WH		
*	40	ZF014900 KEY BLOCK R	拍 子 木 R	DGX-650B		
*	40	ZF015000 KEY BLOCK R	拍 子 木 R	DGX-650WH		
50	--	PB ESCUTCHEON_ASSEMBLY	P B エ ス カ A s s ' y	DGX-650B (ZF01510)		
50	--	PB ESCUTCHEON_ASSEMBLY	P B エ ス カ A s s ' y	DGX-650WH (ZF01520)		
60	WE95460R	BIND HEAD TAPPING SCREW-1	T P # 1 + B I N D		12	01
70	--	FELT	フ ェ ル ト	(ZA69300)		
80	--	CUSHION(PE)	ク ッ シ ョ ン (P E)	(WH39010)	2	
90	--	CUSHION(PE)	ク ッ シ ョ ン (P E)	(WH39020)	2	
100	--	CUSHION	ク ッ シ ョ ン	(WT98140)		
110	--	NONWOVEN CLOTH	不 織 布	(WC45050)	8	
120	--	NONWOVEN CLOTH	不 織 布	(WD26380)		

* : New Parts


RANK : Japan only

■ BOTTOM BOARD ASSEMBLY


● Top view 1



● Bottom view



● Top view 2




REF NO.	PART NO.	DESCRIPTION	部 品 名	REMARKS	QTY	RANK
*	ZF009000	BOTTOM BOARD ASSEMBLY	底 板 A s s y	DGX-650B/DGX-650WH		
10	--	BOTTOM BOARD ASSEMBLY	底 板 A s s y			
10a	--	BOTTOM SUB ASSEMBLY	底 板 木 部 集 成	(ZF01530)		
10b	--	NUT	ナ ッ ト オ ニ メ	(WF58240)	2	
	--	NUT	ナ ッ ト オ ニ メ	(WF73830)	4	
20	--	SPEAKER BOX L	ス ピ ー カ ー ボ ッ ク ス L	(ZE59740)		
30	--	SPEAKER BOX R	ス ピ ー カ ー ボ ッ ク ス R	(ZE59750)		
50	YF014A00	LOUD SPEAKER	ス ピ ー カ ー	Woofer	2	
S60	--	CONNECTOR ASSEMBLY	S P A 束 線	(ZF51030)		
100	WE99860R	BIND HEAD TAPPING SCREW-B	B タ イ ト + B I N D		10	01
110	WE95460R	BIND HEAD TAPPING SCREW-1	T P # 1 + B I N D		16	01
120	--	SPACER	ス ペ ー サ	(WU17530)	15	
130	--	CUSHION(PE)	ク ッ シ ョ ン (P E)	(WF26940)	2	
140	--	CUSHION	ク ッ シ ョ ン	(WU17520)	2	
150	--	CUSHION(PE)	ク ッ シ ョ ン (P E)	(WT98180)	4	
160	--	CUSHION(PE)	ク ッ シ ョ ン (P E)	(WT98190)	4	
170	--	FILAMENT TAPE	粘 着 テ ー プ	(VA12610)	5	
190	--	SUPPORT FRONT RAIL	サ ポ ー ト 金 具	(ZA39270)		
200	WE97090R	BIND HEAD TAPPING SCREW-1	T P # 1 + B I N D		8	01
210	--	SPONGE	吸 音 ス ポ ン ジ	(ZG15180)	2	


* : New Parts

RANK : Japan only


■ KEYBOARD ASSEMBLY



• Hammer, white key



• Hammer, black key




REF NO.	PART NO.	DESCRIPTION		部 品 名	REMARKS	QTY	RANK
* K1	ZC589700	KEYBOARD ASSEMBLY		G H L 鍵盤 A s s ' y	DGX-650B/DGX-650WH		
K2	--	GHL KEYBOARD TEXTURE		G H L 鍵盤 黒 シ ボ D			
K2	MFA27350	GHL B TEXTURE ASSEMBLY		G H L 黒 シ ボ A s s ' y	(WM95930)		
K2	WT973500	FLEXIBLE FLAT CABLE	27P L=350 P=1.0	カ ー ド 電 線			04
K3	--	FLEXIBLE FLAT CABLE	27P L=350 P=1.0	カ ー ド 電 線			
K3	--	FILAMENT TAPE	12X60	粘 着 テ ー プ	(VM72270)	2	
K3	--	FILAMENT TAPE	12X50	フ ィ ラ メ ン ト テ ー プ	(WM77590)	2	
K4	--	SPONGE13		防 振 ス ポ ン ジ 1 3	(WK89530)		
	--						
10	--	GHL B TEXTURE ASSEMBLY		G H L 黒 シ ボ A s s ' y	(WM95930)		
21	--	KEYBOARD FRAME GHL		フ レ ー ム 8 8 改	(WJ02700)		
21a	--	WHITE KEY OCT ASSEMBLY		白 鍵 O C T A s s ' y	(WN53600)	7	
21aa	--	WHITE KEY OCT SUB		白 鍵 O C T サ ブ A s s ' y	(WN53620)		
21ab	WJ029600	WHITE KEYS	CEGB	白 鍵 C E G B 改			03
21ab	WJ029700	WHITE KEYS	DFA	白 鍵 D F A 改			03
21b	WG43760R	ACTUATE RUBBER	GHL	駆 動 ラ バ ー		7	01
21b	WN742300	ACTUATE RUBBER	GHL	駆 動 ラ バ ー		7	01
21c	WN045200	B KEY TEXTURE ASSEMBLY		黒 鍵 シ ボ A s s ' y			05
21ca	--	BLACK KEY TEXTURE		黒 鍵 シ ボ	(WM81240)		
21cb	WG43760R	ACTUATE RUBBER	GHL	駆 動 ラ バ ー		5	01
21cb	WN742300	ACTUATE RUBBER	GHL	駆 動 ラ バ ー		5	01
51	--	WHITE KEY DASH ASSEMBLY		白 鍵 ダ ッ シ ュ A s s ' y	(WN53610)		
51a	--	WHITE KEY DASH SUB		白 鍵 ダ ッ シ ュ サ ブ A s s ' y	(WN53640)		
51aa	WJ029900	WHITE KEY	A'	白 鍵 A 改			01
51ab	WJ030000	WHITE KEY	B'	白 鍵 B 改			01
51ac	WJ030100	WHITE KEY	C'	白 鍵 C 改			02
51b	WG43760R	ACTUATE RUBBER	GHL	駆 動 ラ バ ー		3	01
51b	WN742300	ACTUATE RUBBER	GHL	駆 動 ラ バ ー		3	01
51c	WN045300	A# B KEY TEXTUR		A # 黒 鍵 シ ボ A s s ' y			03
51ca	--	BLACK KEY TEXTURE	A#	黒 鍵 シ ボ A #	(WN04510)		
51cb	WG43760R	ACTUATE RUBBER	GHL	駆 動 ラ バ ー			01
51cb	WN742300	ACTUATE RUBBER	GHL	駆 動 ラ バ ー			01
90	WF15140R	HAMMER ASSEMBLY, WHITE KEY	W1	ハ ン マ ー W 1		13	02
100	WF15150R	HAMMER ASSEMBLY, WHITE KEY	W2	ハ ン マ ー W 2		13	02
110	WF15160R	HAMMER ASSEMBLY, WHITE KEY	W3	ハ ン マ ー W 3		13	02
120	WF15170R	HAMMER ASSEMBLY, WHITE KEY	W4	ハ ン マ ー W 4		13	02
130	WF15180R	HAMMER ASSEMBLY, BLACK KEY	B1	ハ ン マ ー B 1		9	02
140	WF15190R	HAMMER ASSEMBLY, BLACK KEY	B2	ハ ン マ ー B 2		9	02
150	WF15200R	HAMMER ASSEMBLY, BLACK KEY	B3	ハ ン マ ー B 3		9	02
160	WF15210R	HAMMER ASSEMBLY, BLACK KEY	B4	ハ ン マ ー B 4		9	02
170	WF21200R	STOPPER U88		ス ト ッ パ ー U 8 8			07
180	WK688700	STOPPER L88		ス ト ッ パ ー L 8 8			07
190	WF211900	LIMIT STOPPER		リ ミ ッ ト ス ト ッ パ ー			02
200	WF212202	RUBBER CONTACT	GHL OCT 2M	接 点 ゴ ム O C T	C#0-C1,C#1-C2,C#2-C3, C#3-C4,C#4-C5,C#5-C6, C#6-C7	7	05
					A-1-C0		
210	WF212402	RUBBER CONTACT	GHL A-C 2M	接 点 ゴ ム A ー C			05
230	WG317500	CIRCUIT BOARD	GHL88	G H L 8 8 シ ー ト			
230a	WF21250R	CIRCUIT BOARD	GHL88L	G H L 8 8 シ ー ト L			13
230b	WF21260R	CIRCUIT BOARD	GHL88M	G H L 8 8 シ ー ト M			13
230c	WF21280R	CIRCUIT BOARD	GHL88H	G H L 8 8 シ ー ト H			12
230d	WF212900	CONNECTOR ASSEMBLY	17P	中 継 束 線		2	03
260	WF267300	BIND HEAD P-TIGHT SCREW	2.6X8 MFZN2W3	P タ イ ト + B I N D		18	01
270	WE973000	BIND HEAD TAPPING SCREW-P	3.0X16 MFZN2W3	P タ イ ト + B I N D		31	
280	WH711300	SPONGE GHS		防 振 ス ポ ン ジ G H S			
290	WM498600	GREASE_BLUE	G-1066Y 16KG	グ リ ス 青			

*: New Parts

RANK : Japan only

FOOT PEDAL



REF NO.	PART NO.	DESCRIPTION	部 品 名	REMARKS	QTY	RANK
	WU089600	FOOT PEDAL	フットペダル	DGX-650B/DGX-650WH		
	WT733000	PEDAL FINAL ASSEMBLY	フットペダル			10
10	--	UPPER CASE ASSEMBLY	ペダル総組立			10
20	--	LOWER CASE ASSEMBLY	上ケース A s s ' y	(WT75570)		
30	--	PEDAL SPRING	下ケース A s s ' y	(WT75580)		
40	--	SHAFT BUSH	ペダルばね	(WT97780)		
S10	WF303500	BIND HEAD SCREW	回転軸ブッシュ	(WT97820)	2	
			小ネジ + B I N D		2	
	--	UPPER CASE ASSEMBLY	上ケース A s s ' y	(WT75570)		
U10	--	UPPER CASE	上 ケ ー ス	(WT73310)		
U20	--	PEDAL FELT(1)	ペダルフェルト (1)	(WT97790)		
U30	--	PEDAL FELT(2)	ペダルフェルト (2)	(WT99170)		
	--	LOWER CASE ASSEMBLY	下ケース A s s ' y	(WT75580)		
L10	--	LOWER CASE	下 ケ ー ス	(WT73320)		
L20	--	RUBBER SHEET ASSEMBLY	ゴム底 A s s ' y	(WU00640)		
L20a	--	RUBBER BOTTOM SHEET	ゴム底シート	(WT75590)		
L20b	--	ADHESIVE TAPE	粘 着 テ ー プ	(WU05470)		
L30	--	FIXED ANGLE	固 定 金 具	(WT97800)		
L40	--	LEAF SWITCH ASSEMBLY	リーフスイッチ A s s ' y	(WT97810)	2	
L40a	WK233100	LEAF SWITCH	リーフスイッチ			05
L40b	--	WIRE ASSEMBLY	ケーブル加工品	(WU01670)		
LS10	WR901300	BIND HEAD TAPPING SCREW-B	B タイト + B I N D			01

■ ELECTRICAL PARTS

AJACK,DJACK,PB,USB

REF NO.	PART NO.	DESCRIPTION	部 品 名	REMARKS	QTY	RANK
		ELECTRICAL PARTS	電 気 部 品	DGX-650B/DGX-650WH		
* * *	ZE901800	CIRCUIT BOARD	AJACK	(ZE90110)(YE942C0)		
* * *	ZE901400	CIRCUIT BOARD	DJACK	(ZE90110)(YE942C0)		
* * *	ZE902800	CIRCUIT BOARD	PB	(ZE90110)(YE942C0)		
* * *	ZE902000	CIRCUIT BOARD	USB	(ZE90110)(YE942C0)		
	ZE901300	CIRCUIT BOARD	DM	(YE941C0)		
	WF21280R	CIRCUIT BOARD	GHL88H	(WF46250)(X6246D0)	12	
	WF21250R	CIRCUIT BOARD	GHL88L	(WF46230)(X6244D0)	13	
	WF21260R	CIRCUIT BOARD	GHL88M	(WF46240)(X6245G0)	13	
	--	CIRCUIT BOARD	MKO	(ZE90270)(ZE90120)		
				(YE943B0)		
* * *	ZE902200	CIRCUIT BOARD	MVR	(ZE90120)(YE943B0)		
* * *	ZE901900	CIRCUIT BOARD	PEDAL	(ZE90120)(YE943B0)		
* * *	ZE901500	CIRCUIT BOARD	PNL	(ZE90120)(YE943B0)		
* * *	ZE901700	CIRCUIT BOARD	PNR	(ZE90120)(YE943B0)		
* * *	ZE902100	CIRCUIT BOARD	PWR	(ZE90120)(YE943B0)		
* * *	ZE901800	CIRCUIT BOARD	AJACK	(ZE90110)(YE942C0)		
* * *	ZE901400	CIRCUIT BOARD	DJACK	(ZE90110)(YE942C0)		
* * *	ZE902800	CIRCUIT BOARD	PB	(ZE90110)(YE942C0)		
* * *	ZE902000	CIRCUIT BOARD	USB	(ZE90110)(YE942C0)		
70	WQ778800	FUSE HOLDER	PIN TP00526-31			01
80	--	NONWOVENS	35_3	(WC45010)	2	
90	--	NONWOVEN FABRIC	50X3X0.35	(WH21960)		
C544	UR749470	ELECTROLYTIC CAPACITOR	4700 25.0V FORM.			
CN101	VK024600	CONNECTOR	52147 2P TE			
CN103	VK024700	CONNECTOR	52147 3P TE			
CN401	VK024700	CONNECTOR	52147 3P TE			
CN402	WA521800	CONNECTOR	52806 18P TE			
CN403	VK024800	CONNECTOR	52147 4P TE			
CN407	VI878200	CONNECTOR	51048 4P TE			
CN408	VI878200	CONNECTOR	51048 4P TE			
CN409	VB390100	CONNECTOR	PH 5P TE			
CN410	WA780300	CONNECTOR	52806 5P TE			
CN411	VB858400	CONNECTOR	PH 5P SE			
CN415	VL844800	CONNECTOR	XH 4P TE			
CN418	VL844900	CONNECTOR	XH 5P TE			
CN419	LB918020	CONNECTOR	XH 2P TE			
CN420	VL844700	CONNECTOR	XH 3P TE			
CN422	LB932020	CONNECTOR	VH 2P TE			
CN423	VK024600	CONNECTOR	52147 2P TE			
△ D1	WV008801	DIODE	2A02-A0 TE- 52			
△ FT1	ZA675500	FET KB-290	TJ20A10M3 SUTO			
FZ1	KB000690	FUSE 2.5AT	T L 2.50A S			
J17	--	JUMPER CABLE	0.55 TIN			
				(VA07890)		
JK201	WJ306200	CONNECTOR	MSJ-064-15A B AG	PHONES/OUTPUT		01
JK301	VC68750R	CONNECTOR	JACK YKB21-5014	} SUSTAIN		01
JK301	WE24520R	CONNECTOR	JY-6314-01-020			
JK302	V6802600	CONNECTOR	USB 4P SE	USB TO HOST		02
JK303	WK450700	CONNECTOR	YKF45-0033N 4P SE	USB TO DEVICE		01
△ JK305	WZ704400	CONNECTOR	DC-502-AG-PBT-2.0-	DC-IN		01
JK306	V9280100	CONNECTOR	JY-3535-01-070	AUX IN		02
JK306	ZA590000	CONNECTOR	JACK MINI STEREO	} CONTRAST		01
JK306	ZF179900	CONNECTOR	MINI JACK HTJ-035-			
VR301	VV04910R	ROTARY VARIABLE RESISTOR	B 10K RK09K1110	PITCH BEND		02
VR401	WZ510000	ROTARY VARIABLE RESISTOR	B 10.0K RK11K1110D			
W1	--	WIRING ASSEMBLY DCC	4P L=40	(ZF63380)		
C520	US065100	CERAMIC CAPACITOR (CHIP)	0.100 50V Z RECT.			
C524	US062100	CERAMIC CAPACITOR (CHIP)	100P 50V J RECT.			
C526	US063100	CERAMIC CAPACITOR (CHIP)	1000P 50V K RECT.			
C527	US062100	CERAMIC CAPACITOR (CHIP)	100P 50V J RECT.			
C528	US063100	CERAMIC CAPACITOR (CHIP)	1000P 50V K RECT.			
C529	US062470	CERAMIC CAPACITOR (CHIP)	470P 50V J RECT.			
C531	US062100	CERAMIC CAPACITOR (CHIP)	100P 50V J RECT.			
C533	US062470	CERAMIC CAPACITOR (CHIP)	470P 50V J RECT.			
C553	US065100	CERAMIC CAPACITOR (CHIP)	0.100 50V Z RECT.			
C554	US062100	CERAMIC CAPACITOR (CHIP)	100P 50V J RECT.			
C555	US062100	CERAMIC CAPACITOR (CHIP)	100P 50V J RECT.			
C556	US065100	CERAMIC CAPACITOR (CHIP)	0.100 50V Z RECT.			
C557	US062820	CERAMIC CAPACITOR (CHIP)	820P 50V K RECT.			

*: New Parts

RANK : Japan only

AJACK,DJACK,PB,USB,DM

REF NO.	PART NO.	DESCRIPTION	部 品 名	REMARKS	QTY	RANK
-559 IC4	US062820 YA326A00	CERAMIC CAPACITOR (CHIP) IC	820P 50V K RECT. BA4580RF-E2 OPAMP	チ ッ プ セ ラ (B) C OPAMP		01
R304	RD356470	CARBON RESISTOR (CHIP)	4.7K 63M J RECT.	チ ッ プ 抵 抗		
R305	RD356360	CARBON RESISTOR (CHIP)	3.6K 63M J RECT.	チ ッ プ 抵 抗		
R307	RD355100	CARBON RESISTOR (CHIP)	100.0 63M J RECT.	チ ッ プ 抵 抗		
R308	RD355100	CARBON RESISTOR (CHIP)	100.0 63M J RECT.	チ ッ プ 抵 抗		
R309	RD350000	CARBON RESISTOR (CHIP)	0 63M J RECT.	チ ッ プ 抵 抗		
R311	RD358100	CARBON RESISTOR (CHIP)	100.0K 63M J RECT.	チ ッ プ 抵 抗		01
R312	RD350000	CARBON RESISTOR (CHIP)	0 63M J RECT.	チ ッ プ 抵 抗		
R313	RD356390	CARBON RESISTOR (CHIP)	3.9K 63M J RECT.	チ ッ プ 抵 抗		
R314	RD356390	CARBON RESISTOR (CHIP)	3.9K 63M J RECT.	チ ッ プ 抵 抗		
R316	RD350000	CARBON RESISTOR (CHIP)	0 63M J RECT.	チ ッ プ 抵 抗		
R317	RD358100	CARBON RESISTOR (CHIP)	100.0K 63M J RECT.	チ ッ プ 抵 抗		01
R318	RD350000	CARBON RESISTOR (CHIP)	0 63M J RECT.	チ ッ プ 抵 抗		
R330	RD356680	CARBON RESISTOR (CHIP)	6.8K 63M J RECT.	チ ッ プ 抵 抗		
R332	RD356680	CARBON RESISTOR (CHIP)	6.8K 63M J RECT.	チ ッ プ 抵 抗		
R333	RD155100	CARBON RESISTOR (CHIP)	100.0 1/4 J TP	チ ッ プ 抵 抗		
-336	RD155100	CARBON RESISTOR (CHIP)	100.0 1/4 J TP	チ ッ プ 抵 抗		
C519	UR838100	ELECTROLYTIC CAPACITOR	100.00 16.0V RX TP	ケ ミ コ ン		
C521	UR867100	ELECTROLYTIC CAPACITOR	10.00 50.0V RX TP	ケ ミ コ ン		
C522	UR867100	ELECTROLYTIC CAPACITOR	10.00 50.0V RX TP	ケ ミ コ ン		
C525	UN867100	ELECTROLYTIC CAPACITOR BP	10.00 50.0V RX TP	B P ケ ミ コ ン		
C532	UN867100	ELECTROLYTIC CAPACITOR BP	10.00 50.0V RX TP	B P ケ ミ コ ン		
C535	US063220	CERAMIC CAPACITOR (CHIP)	2200P 50V K RECT.	チ ッ プ セ ラ (B)		
C536	US063220	CERAMIC CAPACITOR (CHIP)	2200P 50V K RECT.	チ ッ プ セ ラ (B)		
C540	US065100	CERAMIC CAPACITOR (CHIP)	0.100 50V Z RECT.	チ ッ プ セ ラ F		
C541	US065100	CERAMIC CAPACITOR (CHIP)	0.100 50V Z RECT.	チ ッ プ セ ラ F		
C546	US065100	CERAMIC CAPACITOR (CHIP)	0.100 50V Z RECT.	チ ッ プ セ ラ F		
-548	US065100	CERAMIC CAPACITOR (CHIP)	0.100 50V Z RECT.	チ ッ プ セ ラ F		
C551	UN866330	ELECTROLYTIC CAPACITOR BP	3.30 50.0V RX TP	B P ケ ミ コ ン		
C552	UN866330	ELECTROLYTIC CAPACITOR BP	3.30 50.0V RX TP	B P ケ ミ コ ン		
L301	V2993400	COIL 20UH	R-5C TE-	チ ョ ー ク コ イ ル		01
L302	V2993400	COIL 20UH	R-5C TE-	チ ョ ー ク コ イ ル		01
L303	GE300670	FERRITE	BL02RN2R1P1A	フ ェ ラ イ ト ビ ー ズ		02
L305	GE300670	FERRITE	BL02RN2R1P1A	フ ェ ラ イ ト ビ ー ズ		02
L306	V2993400	COIL 20UH	R-5C TE-	チ ョ ー ク コ イ ル		01
L307	V2993400	COIL 20UH	R-5C TE-	チ ョ ー ク コ イ ル		01
L308	ZC240800	INDUCTOR OTHERS	UF1815SG-800Y3R0-0	ラ イ ン フィ ル タ ー		01
L309	V2993400	COIL 20UH	R-5C TE-	チ ョ ー ク コ イ ル		01
TR301	V2797700	TRANSISTOR	2SC5395-T112-E/F	ト ラ ン ジ ス タ 2 S C		
TR301	WC398400	TRANSISTOR	2N5551C-AT/P	ト ラ ン ジ ス タ		01
TR302	V2797700	TRANSISTOR	2SC5395-T112-E/F	ト ラ ン ジ ス タ 2 S C		
TR302	WC398400	TRANSISTOR	2N5551C-AT/P	ト ラ ン ジ ス タ		01
D2	VB941200	DIODE	1SS133,1SS176 TE-5	ダ イ オ ー ド		
D3	VB941200	DIODE	1SS133,1SS176 TE-5	ダ イ オ ー ド		
J16	--	JUMPER CABLE	0.55 TIN	ジ ャ ン パ ー 線	(VA07890)	
R301	HF456180	CARBON RESISTOR	1.8K 1/4 J AX TP	カ ー ボ ン 抵 抗		
R302	HF457330	CARBON RESISTOR	33.0K 1/4 J AX TP	カ ー ボ ン 抵 抗		
R303	HF456470	CARBON RESISTOR	4.7K 1/4 J AX TP	カ ー ボ ン 抵 抗		01
R319	HF454100	CARBON RESISTOR	10.0 1/4 J AX TP	カ ー ボ ン 抵 抗		
R320	HF454100	CARBON RESISTOR	10.0 1/4 J AX TP	カ ー ボ ン 抵 抗		
R323	HF457470	CARBON RESISTOR	47.0K 1/4 J AX TP	カ ー ボ ン 抵 抗		
R325	HF456330	CARBON RESISTOR	3.3K 1/4 J AX TP	カ ー ボ ン 抵 抗		
R327	HF457470	CARBON RESISTOR	47.0K 1/4 J AX TP	カ ー ボ ン 抵 抗		
R328	HF457180	CARBON RESISTOR	18.0K 1/4 J AX TP	カ ー ボ ン 抵 抗		
*	ZE901300	CIRCUIT BOARD	DM	D M シ ー ト	(YE941C0)	
CN012	VL844800	CONNECTOR	XH 4P TE	ベ ー ス ツ キ ポ ス ト		
CN013	LB933020	CONNECTOR	VH 2P SE	ベ ー ス ポ ス ト		
C014	US062100	CERAMIC CAPACITOR (CHIP)	100P 50V J RECT.	チ ッ プ セ ラ (S L)		
C026	US145100	CERAMIC CAPACITOR (CHIP)	0.1000 25V Z RECT.	チ ッ プ セ ラ (F)		
C031	US661470	CERAMIC CAPACITOR (CHIP)	47P 50V J RECT.	チ ッ プ セ ラ (C H)		01
-042	US661470	CERAMIC CAPACITOR (CHIP)	47P 50V J RECT.	チ ッ プ セ ラ (C H)		01
C046	US662100	CERAMIC CAPACITOR (CHIP)	100P 50V J RECT.	チ ッ プ セ ラ (C H)		
C050	US662470	CERAMIC CAPACITOR (CHIP)	470P 50V K RECT.	チ ッ プ セ ラ (B)		01
-064	US662470	CERAMIC CAPACITOR (CHIP)	470P 50V K RECT.	チ ッ プ セ ラ (B)		01
C072	US625100	CERAMIC CAPACITOR (CHIP)	0.100 10V K RECT.	チ ッ プ セ ラ (B J)		01
C087	US633820	CERAMIC CAPACITOR (CHIP)	8200P 16V K RECT.	チ ッ プ セ ラ (B)		01
C089	US633820	CERAMIC CAPACITOR (CHIP)	8200P 16V K RECT.	チ ッ プ セ ラ (B)		01
C090	WB57250R	POLYESTER FILM CAP. (CHIP)	0.0100 16V J RECT.	チ ッ プ マ イ ラ ー		01

*: New Parts

RANK : Japan only

DM

REF NO.	PART NO.	DESCRIPTION	部 品 名	REMARKS	QTY	RANK
C091	WB57250R	POLYESTER FILM CAP. (CHIP)	0.0100 16V J RECT.	チップマ イ ラ ー		01
C103	US634100	CERAMIC CAPACITOR (CHIP)	0.010 16V K RECT.	チップセラ (B)		
C108	US046100	CERAMIC CAPACITOR (CHIP)	1.00 25V K RECT.	チップセラ (B)		01
C109	US046100	CERAMIC CAPACITOR (CHIP)	1.00 25V K RECT.	チップセラ (B)		01
C114	US062100	CERAMIC CAPACITOR (CHIP)	100P 50V J RECT.	チップセラ (S L)		
C115	US062100	CERAMIC CAPACITOR (CHIP)	100P 50V J RECT.	チップセラ (S L)		
C116	US061470	CERAMIC CAPACITOR (CHIP)	47P 50V J RECT.	チップセラ (C H)		
-129	US061470	CERAMIC CAPACITOR (CHIP)	47P 50V J RECT.	チップセラ (C H)		
C133	US634100	CERAMIC CAPACITOR (CHIP)	0.010 16V K RECT.	チップセラ (B)		
C135	US625100	CERAMIC CAPACITOR (CHIP)	0.100 10V K RECT.	チップセラ (B J)		01
C136	US663100	CERAMIC CAPACITOR (CHIP)	1000P 50V K RECT.	チップセラ (B)		01
C139	US625100	CERAMIC CAPACITOR (CHIP)	0.100 10V K RECT.	チップセラ (B J)		01
C155	US625100	CERAMIC CAPACITOR (CHIP)	0.100 10V K RECT.	チップセラ (B J)		01
C164	US625100	CERAMIC CAPACITOR (CHIP)	0.100 10V K RECT.	チップセラ (B J)		01
C168	US625100	CERAMIC CAPACITOR (CHIP)	0.100 10V K RECT.	チップセラ (B J)		01
C169	US625100	CERAMIC CAPACITOR (CHIP)	0.100 10V K RECT.	チップセラ (B J)		01
C172	WG888300	MONOLITHIC CERAMIC CAP(CHIP)	10.0 6.3V K TP	チップ積層セラコン		01
C172	WP882000	CERAMIC CAPACITOR (CHIP)	10U 6.3V K RECT.	チップセラ		
C173	WG888300	MONOLITHIC CERAMIC CAP(CHIP)	10.0 6.3V K TP	チップ積層セラコン		01
C173	WP882000	CERAMIC CAPACITOR (CHIP)	10U 6.3V K RECT.	チップセラ		
C174	US625100	CERAMIC CAPACITOR (CHIP)	0.100 10V K RECT.	チップセラ (B J)		01
-204	US625100	CERAMIC CAPACITOR (CHIP)	0.100 10V K RECT.	チップセラ (B J)		01
C206	US625100	CERAMIC CAPACITOR (CHIP)	0.100 10V K RECT.	チップセラ (B J)		01
-213	US625100	CERAMIC CAPACITOR (CHIP)	0.100 10V K RECT.	チップセラ (B J)		01
C218	US625100	CERAMIC CAPACITOR (CHIP)	0.100 10V K RECT.	チップセラ (B J)		01
C234	US662100	CERAMIC CAPACITOR (CHIP)	100P 50V J RECT.	チップセラ (C H)		
-237	US662100	CERAMIC CAPACITOR (CHIP)	100P 50V J RECT.	チップセラ (C H)		
C241	US625100	CERAMIC CAPACITOR (CHIP)	0.100 10V K RECT.	チップセラ (B J)		01
C245	US625100	CERAMIC CAPACITOR (CHIP)	0.100 10V K RECT.	チップセラ (B J)		01
C248	US625100	CERAMIC CAPACITOR (CHIP)	0.100 10V K RECT.	チップセラ (B J)		01
C253	V8085400	CERAMIC CAPACITOR (CHIP)	0.1000 25V K RECT.	チップセラ (B)		
C254	US662220	CERAMIC CAPACITOR (CHIP)	220P 50V K RECT.	チップセラ (B)		01
C257	US662220	CERAMIC CAPACITOR (CHIP)	220P 50V K RECT.	チップセラ (B)		01
C258	US046100	CERAMIC CAPACITOR (CHIP)	1.00 25V K RECT.	チップセラ (B)		01
C267	US663100	CERAMIC CAPACITOR (CHIP)	1000P 50V K RECT.	チップセラ (B)		01
C269	US662100	CERAMIC CAPACITOR (CHIP)	100P 50V J RECT.	チップセラ (C H)		
C274	US662100	CERAMIC CAPACITOR (CHIP)	100P 50V J RECT.	チップセラ (C H)		
C289	US625100	CERAMIC CAPACITOR (CHIP)	0.100 10V K RECT.	チップセラ (B J)		01
C290	US634100	CERAMIC CAPACITOR (CHIP)	0.010 16V K RECT.	チップセラ (B)		
C291	US663100	CERAMIC CAPACITOR (CHIP)	1000P 50V K RECT.	チップセラ (B)		01
-293	US663100	CERAMIC CAPACITOR (CHIP)	1000P 50V K RECT.	チップセラ (B)		01
C296	US663100	CERAMIC CAPACITOR (CHIP)	1000P 50V K RECT.	チップセラ (B)		01
C297	US634100	CERAMIC CAPACITOR (CHIP)	0.010 16V K RECT.	チップセラ (B)		
C299	US625100	CERAMIC CAPACITOR (CHIP)	0.100 10V K RECT.	チップセラ (B J)		01
C301	US625100	CERAMIC CAPACITOR (CHIP)	0.100 10V K RECT.	チップセラ (B J)		01
C308	US663100	CERAMIC CAPACITOR (CHIP)	1000P 50V K RECT.	チップセラ (B)		01
C309	US663100	CERAMIC CAPACITOR (CHIP)	1000P 50V K RECT.	チップセラ (B)		01
C310	US662470	CERAMIC CAPACITOR (CHIP)	470P 50V K RECT.	チップセラ (B)		01
C311	US662470	CERAMIC CAPACITOR (CHIP)	470P 50V K RECT.	チップセラ (B)		01
C312	US662100	CERAMIC CAPACITOR (CHIP)	100P 50V J RECT.	チップセラ (C H)		
C313	US662100	CERAMIC CAPACITOR (CHIP)	100P 50V J RECT.	チップセラ (C H)		
C315	US625100	CERAMIC CAPACITOR (CHIP)	0.100 10V K RECT.	チップセラ (B J)		01
IC001	YA326A00	IC	BA4580RF-E2 OPAMP	I C OPAMP		01
IC002	YD235A00	IC	R5524N002A-TR-FE	I C USB HIGH-SIDE POWER SW		02
* IC007	YF284E00	IC	MX29LV640EBTI-70G	I C FLASH ROM 64M		
IC009	X4463A00	IC	SN74LV08APWR	I C AND		
IC013	XY806A0R	IC	TC7WH14FU(TE12L,F)	I C INVERTER		02
IC021	YC967A00	IC	MAX9820ETB+T 95MW	I C HEADPHONE AMP		04
IC024	X9347A00	IC	R3112N291A-TR-FE	I C VOLTAGE DETECTOR		01
IC025	XY806A0R	IC	TC7WH14FU(TE12L,F)	I C INVERTER		02
* IC028	YF285E00	IC	S29GL256S90TFI020	I C FLASH ROM 256M		
IC034	XY806A0R	IC	TC7WH14FU(TE12L,F)	I C INVERTER		02
L047	WK139000	CHIP INDUCTANCE	600 BK1005HM601-T	チップインダクタ		01
R006	RD350000	CARBON RESISTOR (CHIP)	0 63M J RECT.	チップ抵抗		
R009	RD355221	CARBON RESISTOR (CHIP)	220.0 63M J RECT.	チップ抵抗		01
R016	RD357100	CARBON RESISTOR (CHIP)	10.0K 63M J RECT.	チップ抵抗		
R017	RD357220	CARBON RESISTOR (CHIP)	22.0K 63M J RECT.	チップ抵抗		
R027	RD458100	CARBON RESISTOR (CHIP)	100.0K 63M J RECT.	チップ抵抗		
R028	RD45522R	CARBON RESISTOR (CHIP)	220.0 63M J RECT.	チップ抵抗		01
R029	RD45522R	CARBON RESISTOR (CHIP)	220.0 63M J RECT.	チップ抵抗		01

*: New Parts

RANK : Japan only

REF NO.	PART NO.	DESCRIPTION	部	品	名	REMARKS	QTY	RANK
R045	RD454680	CARBON RESISTOR (CHIP) 68.0 63M J RECT.	チ	ッ	ブ 抵 抗			01
R046	RD454680	CARBON RESISTOR (CHIP) 68.0 63M J RECT.	チ	ッ	ブ 抵 抗			01
R048	RD454680	CARBON RESISTOR (CHIP) 68.0 63M J RECT.	チ	ッ	ブ 抵 抗			01
R052	RD454680	CARBON RESISTOR (CHIP) 68.0 63M J RECT.	チ	ッ	ブ 抵 抗			01
R054	RD458470	CARBON RESISTOR (CHIP) 470.0K 63M J RECT.	チ	ッ	ブ 抵 抗			
R056	RD458470	CARBON RESISTOR (CHIP) 470.0K 63M J RECT.	チ	ッ	ブ 抵 抗			
R058	RD458470	CARBON RESISTOR (CHIP) 470.0K 63M J RECT.	チ	ッ	ブ 抵 抗			
R060	RD458470	CARBON RESISTOR (CHIP) 470.0K 63M J RECT.	チ	ッ	ブ 抵 抗			
R065	RD454680	CARBON RESISTOR (CHIP) 68.0 63M J RECT.	チ	ッ	ブ 抵 抗			01
R067	RD455560	CARBON RESISTOR (CHIP) 560.0 63M J RECT.	チ	ッ	ブ 抵 抗			
R068	RD455560	CARBON RESISTOR (CHIP) 560.0 63M J RECT.	チ	ッ	ブ 抵 抗			
R073	RD45000R	CARBON RESISTOR (CHIP) 0.00 63M J RECT.	チ	ッ	ブ 抵 抗			01
R074	RD45000R	CARBON RESISTOR (CHIP) 0.00 63M J RECT.	チ	ッ	ブ 抵 抗			01
R076	RD458100	CARBON RESISTOR (CHIP) 100.0K 63M J RECT.	チ	ッ	ブ 抵 抗			
R078	RD458100	CARBON RESISTOR (CHIP) 100.0K 63M J RECT.	チ	ッ	ブ 抵 抗			
R081	RD457330	CARBON RESISTOR (CHIP) 33.0K 63M J RECT.	チ	ッ	ブ 抵 抗			01
R082	RD457330	CARBON RESISTOR (CHIP) 33.0K 63M J RECT.	チ	ッ	ブ 抵 抗			01
R084	RD45747R	CARBON RESISTOR (CHIP) 47.0K 63M J RECT.	チ	ッ	ブ 抵 抗			01
R085	RD45747R	CARBON RESISTOR (CHIP) 47.0K 63M J RECT.	チ	ッ	ブ 抵 抗			01
R091	RD356100	CARBON RESISTOR (CHIP) 1.0K 63M J RECT.	チ	ッ	ブ 抵 抗			01
R092	RD356100	CARBON RESISTOR (CHIP) 1.0K 63M J RECT.	チ	ッ	ブ 抵 抗			01
R097	RD454330	CARBON RESISTOR (CHIP) 33.0 63M J RECT.	チ	ッ	ブ 抵 抗			
R098	RD454680	CARBON RESISTOR (CHIP) 68.0 63M J RECT.	チ	ッ	ブ 抵 抗			01
R099	RD457100	CARBON RESISTOR (CHIP) 10.0K 63M J RECT.	チ	ッ	ブ 抵 抗			
R101	RD456100	CARBON RESISTOR (CHIP) 1.0K 63M J RECT.	チ	ッ	ブ 抵 抗			
R103	RD454680	CARBON RESISTOR (CHIP) 68.0 63M J RECT.	チ	ッ	ブ 抵 抗			01
R104	RD454680	CARBON RESISTOR (CHIP) 68.0 63M J RECT.	チ	ッ	ブ 抵 抗			01
R106	RD454680	CARBON RESISTOR (CHIP) 68.0 63M J RECT.	チ	ッ	ブ 抵 抗			01
R107	RD454680	CARBON RESISTOR (CHIP) 68.0 63M J RECT.	チ	ッ	ブ 抵 抗			01
R109	RD454680	CARBON RESISTOR (CHIP) 68.0 63M J RECT.	チ	ッ	ブ 抵 抗			01
R113	RD454680	CARBON RESISTOR (CHIP) 68.0 63M J RECT.	チ	ッ	ブ 抵 抗			01
R114	RD454680	CARBON RESISTOR (CHIP) 68.0 63M J RECT.	チ	ッ	ブ 抵 抗			01
R116	RD454680	CARBON RESISTOR (CHIP) 68.0 63M J RECT.	チ	ッ	ブ 抵 抗			01
R117	RD457100	CARBON RESISTOR (CHIP) 10.0K 63M J RECT.	チ	ッ	ブ 抵 抗			
R118	RD457100	CARBON RESISTOR (CHIP) 10.0K 63M J RECT.	チ	ッ	ブ 抵 抗			
R119	RD456100	CARBON RESISTOR (CHIP) 1.0K 63M J RECT.	チ	ッ	ブ 抵 抗			
R120	RD454680	CARBON RESISTOR (CHIP) 68.0 63M J RECT.	チ	ッ	ブ 抵 抗			01
R121	RD454680	CARBON RESISTOR (CHIP) 68.0 63M J RECT.	チ	ッ	ブ 抵 抗			01
R128	RD454220	CARBON RESISTOR (CHIP) 22.0 63M J RECT.	チ	ッ	ブ 抵 抗			
R129	RD454220	CARBON RESISTOR (CHIP) 22.0 63M J RECT.	チ	ッ	ブ 抵 抗			
R132	RD454220	CARBON RESISTOR (CHIP) 22.0 63M J RECT.	チ	ッ	ブ 抵 抗			
R134	RD454220	CARBON RESISTOR (CHIP) 22.0 63M J RECT.	チ	ッ	ブ 抵 抗			
R138	RD456100	CARBON RESISTOR (CHIP) 1.0K 63M J RECT.	チ	ッ	ブ 抵 抗			
R140	RD457100	CARBON RESISTOR (CHIP) 10.0K 63M J RECT.	チ	ッ	ブ 抵 抗			
-142	RD457100	CARBON RESISTOR (CHIP) 10.0K 63M J RECT.	チ	ッ	ブ 抵 抗			
R149	RD457100	CARBON RESISTOR (CHIP) 10.0K 63M J RECT.	チ	ッ	ブ 抵 抗			
R152	RD454680	CARBON RESISTOR (CHIP) 68.0 63M J RECT.	チ	ッ	ブ 抵 抗			01
-156	RD454680	CARBON RESISTOR (CHIP) 68.0 63M J RECT.	チ	ッ	ブ 抵 抗			01
R158	RD454680	CARBON RESISTOR (CHIP) 68.0 63M J RECT.	チ	ッ	ブ 抵 抗			01
R159	RD456100	CARBON RESISTOR (CHIP) 1.0K 63M J RECT.	チ	ッ	ブ 抵 抗			
R160	RD45747R	CARBON RESISTOR (CHIP) 47.0K 63M J RECT.	チ	ッ	ブ 抵 抗			01
R165	RD457100	CARBON RESISTOR (CHIP) 10.0K 63M J RECT.	チ	ッ	ブ 抵 抗			
R166	RD455100	CARBON RESISTOR (CHIP) 100.0 63M J RECT.	チ	ッ	ブ 抵 抗			
-169	RD455100	CARBON RESISTOR (CHIP) 100.0 63M J RECT.	チ	ッ	ブ 抵 抗			
R171	RD457100	CARBON RESISTOR (CHIP) 10.0K 63M J RECT.	チ	ッ	ブ 抵 抗			
-177	RD457100	CARBON RESISTOR (CHIP) 10.0K 63M J RECT.	チ	ッ	ブ 抵 抗			
R178	RD45000R	CARBON RESISTOR (CHIP) 0.00 63M J RECT.	チ	ッ	ブ 抵 抗			01
R183	RD454680	CARBON RESISTOR (CHIP) 68.0 63M J RECT.	チ	ッ	ブ 抵 抗			01
R184	RD456100	CARBON RESISTOR (CHIP) 1.0K 63M J RECT.	チ	ッ	ブ 抵 抗			
R185	RD456100	CARBON RESISTOR (CHIP) 1.0K 63M J RECT.	チ	ッ	ブ 抵 抗			
R188	RD457100	CARBON RESISTOR (CHIP) 10.0K 63M J RECT.	チ	ッ	ブ 抵 抗			
R197	RD457100	CARBON RESISTOR (CHIP) 10.0K 63M J RECT.	チ	ッ	ブ 抵 抗			
-199	RD457100	CARBON RESISTOR (CHIP) 10.0K 63M J RECT.	チ	ッ	ブ 抵 抗			
R200	RD454680	CARBON RESISTOR (CHIP) 68.0 63M J RECT.	チ	ッ	ブ 抵 抗			01
R206	RD454680	CARBON RESISTOR (CHIP) 68.0 63M J RECT.	チ	ッ	ブ 抵 抗			01
R207	RD454680	CARBON RESISTOR (CHIP) 68.0 63M J RECT.	チ	ッ	ブ 抵 抗			01
R228	RD457150	CARBON RESISTOR (CHIP) 15.0K 63M J RECT.	チ	ッ	ブ 抵 抗			01
R229	RD457150	CARBON RESISTOR (CHIP) 15.0K 63M J RECT.	チ	ッ	ブ 抵 抗			01
R230	RD45000R	CARBON RESISTOR (CHIP) 0.00 63M J RECT.	チ	ッ	ブ 抵 抗			01
R231	RD253100	CARBON RESISTOR (CHIP) 1.0 0.1 J RECT.	チ	ッ	ブ 抵 抗			

* : New Parts

RANK : Japan only

DM

REF NO.	PART NO.	DESCRIPTION	部 品 名	REMARKS	QTY	RANK
R236	RD457100	CARBON RESISTOR (CHIP)	10.0K 63M J RECT.	チ ッ ブ 抵 抗		
R239	RD45615R	CARBON RESISTOR (CHIP)	1.5K 63M J RECT.	チ ッ ブ 抵 抗		01
R249	RD45747R	CARBON RESISTOR (CHIP)	47.0K 63M J RECT.	チ ッ ブ 抵 抗		01
R252	RD45000R	CARBON RESISTOR (CHIP)	0.00 63M J RECT.	チ ッ ブ 抵 抗		01
R257	RD455100	CARBON RESISTOR (CHIP)	100.0 63M J RECT.	チ ッ ブ 抵 抗		
R258	RD455100	CARBON RESISTOR (CHIP)	100.0 63M J RECT.	チ ッ ブ 抵 抗		
R279	RD454220	CARBON RESISTOR (CHIP)	22.0 63M J RECT.	チ ッ ブ 抵 抗		
R284	RD456470	CARBON RESISTOR (CHIP)	4.7K 63M J RECT.	チ ッ ブ 抵 抗		
-287	RD456470	CARBON RESISTOR (CHIP)	4.7K 63M J RECT.	チ ッ ブ 抵 抗		
R290	RD45000R	CARBON RESISTOR (CHIP)	0.00 63M J RECT.	チ ッ ブ 抵 抗		01
R291	RD45000R	CARBON RESISTOR (CHIP)	0.00 63M J RECT.	チ ッ ブ 抵 抗		01
R292	RD457100	CARBON RESISTOR (CHIP)	10.0K 63M J RECT.	チ ッ ブ 抵 抗		
R298	RD45747R	CARBON RESISTOR (CHIP)	47.0K 63M J RECT.	チ ッ ブ 抵 抗		01
R305	RD45000R	CARBON RESISTOR (CHIP)	0.00 63M J RECT.	チ ッ ブ 抵 抗		01
R306	RD350000	CARBON RESISTOR (CHIP)	0 63M J RECT.	チ ッ ブ 抵 抗		
R307	RD350000	CARBON RESISTOR (CHIP)	0 63M J RECT.	チ ッ ブ 抵 抗		
R308	RD45747R	CARBON RESISTOR (CHIP)	47.0K 63M J RECT.	チ ッ ブ 抵 抗		01
RA014	WH206200	RESISTOR ARRAY	47 X 4	抵 抗 ア レ イ		01
-017	WH206200	RESISTOR ARRAY	47 X 4	抵 抗 ア レ イ		01
RA038	WH205800	RESISTOR ARRAY	33 X 4	抵 抗 ア レ イ		01
-043	WH205800	RESISTOR ARRAY	33 X 4	抵 抗 ア レ イ		01
RA050	WH211800	RESISTOR ARRAY	10K X 4	抵 抗 ア レ イ		01
RA062	WH205400	RESISTOR ARRAY	22 X 4	抵 抗 ア レ イ		01
-065	WH205400	RESISTOR ARRAY	22 X 4	抵 抗 ア レ イ		01
RA067	WH205400	RESISTOR ARRAY	22 X 4	抵 抗 ア レ イ		01
RA077	WH206600	RESISTOR ARRAY	68 X 4	抵 抗 ア レ イ		01
RA078	WH206600	RESISTOR ARRAY	68 X 4	抵 抗 ア レ イ		01
RA081	WH206600	RESISTOR ARRAY	68 X 4	抵 抗 ア レ イ		01
TA001	WC66850R	DIGITAL TRANSISTOR	UMG5N	デ ジ タ ル ト ラ ン ジ ス タ		01
C001	US145100	CERAMIC CAPACITOR (CHIP)	0.1000 25V Z RECT.	チ ッ プ セ ラ (F)		
-008	US145100	CERAMIC CAPACITOR (CHIP)	0.1000 25V Z RECT.	チ ッ プ セ ラ (F)		
C009	US062100	CERAMIC CAPACITOR (CHIP)	100P 50V J RECT.	チ ッ プ セ ラ (S L)		
C010	US062100	CERAMIC CAPACITOR (CHIP)	100P 50V J RECT.	チ ッ プ セ ラ (S L)		
C011	UF037100	ELECTROLYTIC CAPACITOR(CHIP)	10 16V	チ ッ プ ケ ミ コ ン		
C012	US062100	CERAMIC CAPACITOR (CHIP)	100P 50V J RECT.	チ ッ プ セ ラ (S L)		
C013	US062100	CERAMIC CAPACITOR (CHIP)	100P 50V J RECT.	チ ッ プ セ ラ (S L)		
C015	US062100	CERAMIC CAPACITOR (CHIP)	100P 50V J RECT.	チ ッ プ セ ラ (S L)		
C016	US145100	CERAMIC CAPACITOR (CHIP)	0.1000 25V Z RECT.	チ ッ プ セ ラ (F)		
C017	US062100	CERAMIC CAPACITOR (CHIP)	100P 50V J RECT.	チ ッ プ セ ラ (S L)		
-020	US062100	CERAMIC CAPACITOR (CHIP)	100P 50V J RECT.	チ ッ プ セ ラ (S L)		
C021	US063100	CERAMIC CAPACITOR (CHIP)	1000P 50V K RECT.	チ ッ プ セ ラ (B)		
C022	US062390	CERAMIC CAPACITOR (CHIP)	390P 50V J RECT.	チ ッ プ セ ラ (S L)		
C023	UF038100	ELECTROLYTIC CAPACITOR(CHIP)	100 16V	チ ッ プ ケ ミ コ ン		
C024	US063100	CERAMIC CAPACITOR (CHIP)	1000P 50V K RECT.	チ ッ プ セ ラ (B)		
C027	US06127R	CERAMIC CAPACITOR (CHIP)	27P 50V J RECT.	チ ッ プ セ ラ (C H)		01
C028	US06127R	CERAMIC CAPACITOR (CHIP)	27P 50V J RECT.	チ ッ プ セ ラ (C H)		01
C029	US145100	CERAMIC CAPACITOR (CHIP)	0.1000 25V Z RECT.	チ ッ プ セ ラ (F)		
C030	US06127R	CERAMIC CAPACITOR (CHIP)	27P 50V J RECT.	チ ッ プ セ ラ (C H)		01
C047	US625100	CERAMIC CAPACITOR (CHIP)	0.100 10V K RECT.	チ ッ プ セ ラ (B J)		01
C048	UF037100	ELECTROLYTIC CAPACITOR(CHIP)	10 16V	チ ッ プ ケ ミ コ ン		
C049	US625100	CERAMIC CAPACITOR (CHIP)	0.100 10V K RECT.	チ ッ プ セ ラ (B J)		01
C073	WG251600	CERAMIC CAPACITOR (CHIP)	4.7 6.3V K RECT.	チ ッ プ セ ラ		01
C074	UF037100	ELECTROLYTIC CAPACITOR(CHIP)	10 16V	チ ッ プ ケ ミ コ ン		
C075	US625100	CERAMIC CAPACITOR (CHIP)	0.100 10V K RECT.	チ ッ プ セ ラ (B J)		01
C076	US046100	CERAMIC CAPACITOR (CHIP)	1.00 25V K RECT.	チ ッ プ セ ラ (B)		01
C077	WN019700	CERAMIC CAPACITOR (CHIP)	2.200 16V K RECT.	チ ッ プ セ ラ		
C078	US046100	CERAMIC CAPACITOR (CHIP)	1.00 25V K RECT.	チ ッ プ セ ラ (B)		01
C079	WG251600	CERAMIC CAPACITOR (CHIP)	4.7 6.3V K RECT.	チ ッ プ セ ラ		01
C080	UF037100	ELECTROLYTIC CAPACITOR(CHIP)	10 16V	チ ッ プ ケ ミ コ ン		
-082	UF037100	ELECTROLYTIC CAPACITOR(CHIP)	10 16V	チ ッ プ ケ ミ コ ン		
C083	WG969400	MONOLITHIC CERAMIC CAP(CHIP)	10.000 6.3V K KAKU	チ ッ プ 積 層 セ ラ コ ン		01
C084	US625100	CERAMIC CAPACITOR (CHIP)	0.100 10V K RECT.	チ ッ プ セ ラ (B J)		01
-086	US625100	CERAMIC CAPACITOR (CHIP)	0.100 10V K RECT.	チ ッ プ セ ラ (B J)		01
C088	US634100	CERAMIC CAPACITOR (CHIP)	0.010 16V K RECT.	チ ッ プ セ ラ (B)		
C092	WB29110R	ELECTROLYTIC CAPACITOR(CHIP)	35V EEE1VA101UP	チ ッ プ ケ ミ コ ン		
C093	WG969400	MONOLITHIC CERAMIC CAP(CHIP)	10.000 6.3V K KAKU	チ ッ プ 積 層 セ ラ コ ン		01
C094	US634100	CERAMIC CAPACITOR (CHIP)	0.010 16V K RECT.	チ ッ プ セ ラ (B)		
C095	WB51600R	ELECTROLYTIC CAPACITOR(CHIP)	100 6.3V EEEFK0J10	チ ッ プ ケ ミ コ ン		01
C096	WN019700	CERAMIC CAPACITOR (CHIP)	2.200 16V K RECT.	チ ッ プ セ ラ		
C098	WC37000R	ELECTROLYTIC CAPACITOR(CHIP)	220.00 35.0V	チ ッ プ ケ ミ コ ン U D		01

*: New Parts

RANK : Japan only

REF NO.	PART NO.	DESCRIPTION	部 品 名	REMARKS	QTY	RANK
C099	UF06610R	ELECTROLYTIC CAPACITOR(CHIP)	1 50V	チ ッ プ ケ ミ コ ン		01
C100	UF06610R	ELECTROLYTIC CAPACITOR(CHIP)	1 50V	チ ッ プ ケ ミ コ ン		01
C101	UF038100	ELECTROLYTIC CAPACITOR(CHIP)	100 16V	チ ッ プ ケ ミ コ ン		
C102	WG969400	MONOLITHIC CERAMIC CAP(CHIP)	10.000 6.3V K KAKU	チ ッ プ 積 層 セ ラ コ ン		01
C104	UF038100	ELECTROLYTIC CAPACITOR(CHIP)	100 16V	チ ッ プ ケ ミ コ ン		
C105	WG969400	MONOLITHIC CERAMIC CAP(CHIP)	10.000 6.3V K KAKU	チ ッ プ 積 層 セ ラ コ ン		01
C106	WJ590700	CERAMIC CAPACITOR (CHIP)	0.47 16V K RECT.	チ ッ プ セ ラ		
C107	US663100	CERAMIC CAPACITOR (CHIP)	1000P 50V K RECT.	チ ッ プ セ ラ (B)		01
C110	WN110600	MONOLITHIC CERAMIC CAP(CHIP)	4.700 25V K KAKUTE	チ ッ プ 積 層 セ ラ コ ン		01
C111	UF14810R	ELECTROLYTIC CAPACITOR(CHIP)	100 25V	チ ッ プ ケ ミ コ ン		01
C112	WN562400	ELECTROLYTIC CAPACITOR(CHIP)	220.00 16.0V	チ ッ プ ケ ミ コ ン U D		01
C113	US662100	CERAMIC CAPACITOR (CHIP)	100P 50V J RECT.	チ ッ プ セ ラ (C H)		
C132	US063100	CERAMIC CAPACITOR (CHIP)	1000P 50V K RECT.	チ ッ プ セ ラ (B)		
C134	US625100	CERAMIC CAPACITOR (CHIP)	0.100 10V K RECT.	チ ッ プ セ ラ (B J)		01
C137	US661100	CERAMIC CAPACITOR (CHIP)	10P 50V D RECT.	チ ッ プ セ ラ (C H)		01
C138	US661100	CERAMIC CAPACITOR (CHIP)	10P 50V D RECT.	チ ッ プ セ ラ (C H)		01
C140	WG888300	MONOLITHIC CERAMIC CAP(CHIP)	10.0 6.3V K TP	チ ッ プ 積 層 セ ラ コ ン		01
C140	WP882000	CERAMIC CAPACITOR (CHIP)	10U 6.3V K RECT.	チ ッ プ セ ラ		
C141	US625100	CERAMIC CAPACITOR (CHIP)	0.100 10V K RECT.	チ ッ プ セ ラ (B J)		01
-144	US625100	CERAMIC CAPACITOR (CHIP)	0.100 10V K RECT.	チ ッ プ セ ラ (B J)		01
C145	WG888300	MONOLITHIC CERAMIC CAP(CHIP)	10.0 6.3V K TP	チ ッ プ 積 層 セ ラ コ ン		01
C145	WP882000	CERAMIC CAPACITOR (CHIP)	10U 6.3V K RECT.	チ ッ プ セ ラ		
C146	US625100	CERAMIC CAPACITOR (CHIP)	0.100 10V K RECT.	チ ッ プ セ ラ (B J)		01
-153	US625100	CERAMIC CAPACITOR (CHIP)	0.100 10V K RECT.	チ ッ プ セ ラ (B J)		01
C154	WG888300	MONOLITHIC CERAMIC CAP(CHIP)	10.0 6.3V K TP	チ ッ プ 積 層 セ ラ コ ン		01
C154	WP882000	CERAMIC CAPACITOR (CHIP)	10U 6.3V K RECT.	チ ッ プ セ ラ		
C156	US625100	CERAMIC CAPACITOR (CHIP)	0.100 10V K RECT.	チ ッ プ セ ラ (B J)		01
C157	WG888300	MONOLITHIC CERAMIC CAP(CHIP)	10.0 6.3V K TP	チ ッ プ 積 層 セ ラ コ ン		01
C157	WP882000	CERAMIC CAPACITOR (CHIP)	10U 6.3V K RECT.	チ ッ プ セ ラ		
C158	US625100	CERAMIC CAPACITOR (CHIP)	0.100 10V K RECT.	チ ッ プ セ ラ (B J)		01
-163	US625100	CERAMIC CAPACITOR (CHIP)	0.100 10V K RECT.	チ ッ プ セ ラ (B J)		01
C165	US625100	CERAMIC CAPACITOR (CHIP)	0.100 10V K RECT.	チ ッ プ セ ラ (B J)		01
-167	US625100	CERAMIC CAPACITOR (CHIP)	0.100 10V K RECT.	チ ッ プ セ ラ (B J)		01
C205	US625100	CERAMIC CAPACITOR (CHIP)	0.100 10V K RECT.	チ ッ プ セ ラ (B J)		01
C214	US625100	CERAMIC CAPACITOR (CHIP)	0.100 10V K RECT.	チ ッ プ セ ラ (B J)		01
-217	US625100	CERAMIC CAPACITOR (CHIP)	0.100 10V K RECT.	チ ッ プ セ ラ (B J)		01
C219	US625100	CERAMIC CAPACITOR (CHIP)	0.100 10V K RECT.	チ ッ プ セ ラ (B J)		01
C220	US625100	CERAMIC CAPACITOR (CHIP)	0.100 10V K RECT.	チ ッ プ セ ラ (B J)		01
C229	US625100	CERAMIC CAPACITOR (CHIP)	0.100 10V K RECT.	チ ッ プ セ ラ (B J)		01
C230	WG888300	MONOLITHIC CERAMIC CAP(CHIP)	10.0 6.3V K TP	チ ッ プ 積 層 セ ラ コ ン		01
C230	WP882000	CERAMIC CAPACITOR (CHIP)	10U 6.3V K RECT.	チ ッ プ セ ラ		
C231	US663100	CERAMIC CAPACITOR (CHIP)	1000P 50V K RECT.	チ ッ プ セ ラ (B)		01
C232	US663100	CERAMIC CAPACITOR (CHIP)	1000P 50V K RECT.	チ ッ プ セ ラ (B)		01
C233	US625100	CERAMIC CAPACITOR (CHIP)	0.100 10V K RECT.	チ ッ プ セ ラ (B J)		01
C238	US625100	CERAMIC CAPACITOR (CHIP)	0.100 10V K RECT.	チ ッ プ セ ラ (B J)		01
-240	US625100	CERAMIC CAPACITOR (CHIP)	0.100 10V K RECT.	チ ッ プ セ ラ (B J)		01
C244	US625100	CERAMIC CAPACITOR (CHIP)	0.100 10V K RECT.	チ ッ プ セ ラ (B J)		01
C246	US625100	CERAMIC CAPACITOR (CHIP)	0.100 10V K RECT.	チ ッ プ セ ラ (B J)		01
C247	US625100	CERAMIC CAPACITOR (CHIP)	0.100 10V K RECT.	チ ッ プ セ ラ (B J)		01
C249	V8085400	CERAMIC CAPACITOR (CHIP)	0.1000 25V K RECT.	チ ッ プ セ ラ (B)		
C250	V8085400	CERAMIC CAPACITOR (CHIP)	0.1000 25V K RECT.	チ ッ プ セ ラ (B)		
C251	WN019700	CERAMIC CAPACITOR (CHIP)	2.200 16V K RECT.	チ ッ プ セ ラ		
C252	V8085400	CERAMIC CAPACITOR (CHIP)	0.1000 25V K RECT.	チ ッ プ セ ラ (B)		
C263	US046100	CERAMIC CAPACITOR (CHIP)	1.00 25V K RECT.	チ ッ プ セ ラ (B)		01
-266	US046100	CERAMIC CAPACITOR (CHIP)	1.00 25V K RECT.	チ ッ プ セ ラ (B)		01
C270	V8085400	CERAMIC CAPACITOR (CHIP)	0.1000 25V K RECT.	チ ッ プ セ ラ (B)		
-273	V8085400	CERAMIC CAPACITOR (CHIP)	0.1000 25V K RECT.	チ ッ プ セ ラ (B)		
C275	US662100	CERAMIC CAPACITOR (CHIP)	100P 50V J RECT.	チ ッ プ セ ラ (C H)		
C276	V8085400	CERAMIC CAPACITOR (CHIP)	0.1000 25V K RECT.	チ ッ プ セ ラ (B)		
-279	V8085400	CERAMIC CAPACITOR (CHIP)	0.1000 25V K RECT.	チ ッ プ セ ラ (B)		
C280	US662100	CERAMIC CAPACITOR (CHIP)	100P 50V J RECT.	チ ッ プ セ ラ (C H)		
C283	V8085400	CERAMIC CAPACITOR (CHIP)	0.1000 25V K RECT.	チ ッ プ セ ラ (B)		
-288	V8085400	CERAMIC CAPACITOR (CHIP)	0.1000 25V K RECT.	チ ッ プ セ ラ (B)		
C294	US663100	CERAMIC CAPACITOR (CHIP)	1000P 50V K RECT.	チ ッ プ セ ラ (B)		01
C295	US663100	CERAMIC CAPACITOR (CHIP)	1000P 50V K RECT.	チ ッ プ セ ラ (B)		01
C300	V8085400	CERAMIC CAPACITOR (CHIP)	0.1000 25V K RECT.	チ ッ プ セ ラ (B)		
C302	US625100	CERAMIC CAPACITOR (CHIP)	0.100 10V K RECT.	チ ッ プ セ ラ (B J)		01
C303	UF038100	ELECTROLYTIC CAPACITOR(CHIP)	100 16V	チ ッ プ ケ ミ コ ン		
C306	UF037100	ELECTROLYTIC CAPACITOR(CHIP)	10 16V	チ ッ プ ケ ミ コ ン		
C307	UF037100	ELECTROLYTIC CAPACITOR(CHIP)	10 16V	チ ッ プ ケ ミ コ ン		

* : New Parts

RANK : Japan only

DM

REF NO.	PART NO.	DESCRIPTION	部 品 名	REMARKS	QTY	RANK
C316	US661220	CERAMIC CAPACITOR (CHIP)	22P 50V J RECT.	チップセラ (C H)		
C317	US661220	CERAMIC CAPACITOR (CHIP)	22P 50V J RECT.	チップセラ (C H)		
C346	US662100	CERAMIC CAPACITOR (CHIP)	100P 50V J RECT.	チップセラ (C H)		
C347	US662100	CERAMIC CAPACITOR (CHIP)	100P 50V J RECT.	チップセラ (C H)		
C348	US662100	CERAMIC CAPACITOR (CHIP)	100P 50V J RECT.	チップセラ (C H)		
C349	US662820	CERAMIC CAPACITOR (CHIP)	820P 50V K RECT.	チップセラ (B)		
C350	US662820	CERAMIC CAPACITOR (CHIP)	820P 50V K RECT.	チップセラ (B)		
CN001	WC199700	CONNECTOR	52808 27P TE	F F C / F P C コネク		03
CN002	WC195200	CONNECTOR	52808 14P TE	F F C / F P C コネク		
CN005	WC19500R	CONNECTOR	52808 12P TE	F F C / F P C コネク		01
CN006	WC195300	CONNECTOR	52808 15P TE	F F C / F P C コネ		01
CN007	WC194500	CONNECTOR	52808 6P TE	F F C / F P C コネク		
CN008	WC19930R	CONNECTOR	52808 18P TE	F F C / F P C コネク		01
CN009	WC194400	CONNECTOR	52808 5P TE	F F C / F P C コネク		01
CN10	VT389100	CONNECTOR	PH 10P TE	ベース付ポスト		
D003	V2376600	DIODE	RB500V-40 TAPING	ショットキダイオード		
D004	VT332900	DIODE	1SS355 TE-17 TP	ダイオード		
-011	VT332900	DIODE	1SS355 TE-17 TP	ダイオード		
D012	WM940400	DIODE	RB070M-30TR TP	ダイオード		01
DA001	V9424900	DIODE ARRAY	1SS372 TE85L	ダイオードアレイ		01
-004	V9424900	DIODE ARRAY	1SS372 TE85L	ダイオードアレイ		01
DA001	WP361700	DIODE ARRAY	KDR731-RTK/P 0.07A	ダイオードアレイ		
-004	WP361700	DIODE ARRAY	KDR731-RTK/P 0.07A	ダイオードアレイ		
IC006	X5422A00	IC	S1D13700F01A100 LC	I C	LCD CONTROLLER	08
IC008	X3294A00	IC	MC34063ECD-TR	I C	DC-DC CONVERTER	
IC012	XZ56010R	IC	UPD789022GB-A15-8E	I C	CPU	05
IC015	YC681B00	IC	WM8524CGEDT/R	I C	DAC	
IC016	X7357B00	IC	PCM1803ADBR	I C	ADC	03
IC017	X9292A00	IC	R1172H121D-T1-FE	I C	REGULATOR +1.2V	01
IC017	YE238A00	IC	RP132H121D-T1-FE 1	I C		
IC019	YD113A00	IC	RP131H331D-T1-FE 3	I C	REGULATOR +3.3V	01
IC020	YD832A00	IC	R1245K003G-TR	I C	DC-DC CONVERTER	02
IC023	--	IC	R8A02042BG	I C	SWX08 (YC479A0)	
IC026	X3584E00	IC	W9812G6JH-6 SDRAM	I C	SDRAM 128M	04
IC027	X3584E00	IC	W9812G6JH-6 SDRAM	I C	SDRAM 128M	04
IC030	X6688A00	IC	SN74LV14APWR INV	I C	INVERTER	
IC031	XZ414F00	IC	W9864G6JH-6 SDRAM	I C	SDRAM 64M	03
IC032	X8506A01	IC	TC74VHC123AFT EL,K	I C	MULTIVIBRATOR	02
IC033	X2377A0R	IC	SN74LV21APWR	I C	AND	01
IC035	YD652A00	IC	YDA164C-QZE2	I C	POWER AMPLIFIER 20Wx2	04
L001	VY657200	CHIP INDUCTANCE	600 BK1608HM601-T	チップインダクタ		
L002	VY657200	CHIP INDUCTANCE	600 BK1608HM601-T	チップインダクタ		
L003	V858970R	CHIP INDUCTANCE	330U SLF7045T-331M	チップインダクタ		02
L004	VY657200	CHIP INDUCTANCE	600 BK1608HM601-T	チップインダクタ		
L005	WK139000	CHIP INDUCTANCE	600 BK1005HM601-T	チップインダクタ		01
-008	WK139000	CHIP INDUCTANCE	600 BK1005HM601-T	チップインダクタ		01
L009	WM457700	COIL	7E04NA-2R4N-R SMD	コイル 2. 4 U		01
L009	ZA324800	CHIP INDUCTANCE	2.4U 7E04NB-2R4N-R	チップインダクタ		01
L010	VY657200	CHIP INDUCTANCE	600 BK1608HM601-T	チップインダクタ		
-020	VY657200	CHIP INDUCTANCE	600 BK1608HM601-T	チップインダクタ		
L022	VY657200	CHIP INDUCTANCE	600 BK1608HM601-T	チップインダクタ		
-034	VY657200	CHIP INDUCTANCE	600 BK1608HM601-T	チップインダクタ		
L038	WK139000	CHIP INDUCTANCE	600 BK1005HM601-T	チップインダクタ		01
L039	WJ018200	CHIP INDUCTANCE	BLM18SG700TN1D 1	チップインダクタ		01
L040	WZ540200	CHIP INDUCTANCE	10U DER7052-100M-R	チップインダクタ		01
-043	WZ540200	CHIP INDUCTANCE	10U DER7052-100M-R	チップインダクタ		01
L045	WE863900	CHIP INDUCTANCE	DLP11SN900HL2L 1	コモンモードコイル		01
L046	WE863900	CHIP INDUCTANCE	DLP11SN900HL2L 1	コモンモードコイル		01
L048	WH559500	CHIP INDUCTANCE	BLM18PG471SN1D 1	チップインダクタ		01
L049	WK139000	CHIP INDUCTANCE	600 BK1005HM601-T	チップインダクタ		01
L050	WK139000	CHIP INDUCTANCE	600 BK1005HM601-T	チップインダクタ		01
R001	RD355100	CARBON RESISTOR (CHIP)	100.0 63M J RECT.	チ ッ プ 抵 抗		
R002	RD356100	CARBON RESISTOR (CHIP)	1.0K 63M J RECT.	チ ッ プ 抵 抗		
R003	RD354220	CARBON RESISTOR (CHIP)	22.0 63M J RECT.	チ ッ プ 抵 抗		01
R004	RD357100	CARBON RESISTOR (CHIP)	10.0K 63M J RECT.	チ ッ プ 抵 抗		
R005	RD357470	CARBON RESISTOR (CHIP)	47.0K 63M J RECT.	チ ッ プ 抵 抗		
R010	RD355221	CARBON RESISTOR (CHIP)	220.0 63M J RECT.	チ ッ プ 抵 抗		01
R011	RD15310R	CARBON RESISTOR (CHIP)	1.0 1/4 J TP	チ ッ プ 抵 抗		01
-013	RD15310R	CARBON RESISTOR (CHIP)	1.0 1/4 J TP	チ ッ プ 抵 抗		01
R014	RD456680	CARBON RESISTOR (CHIP)	6.8K 63M J RECT.	チ ッ プ 抵 抗		

*: New Parts

RANK : Japan only

REF NO.	PART NO.	DESCRIPTION		部	品	名	REMARKS	QTY	RANK
* R015	RD456130	CARBON RESISTOR (CHIP)	1.3K 63M J RECT.	チ	ッ	ブ	抵	抗	
R018	RD357150	CARBON RESISTOR (CHIP)	15.0K 63M J RECT.	チ	ッ	ブ	抵	抗	
R019	RD357150	CARBON RESISTOR (CHIP)	15.0K 63M J RECT.	チ	ッ	ブ	抵	抗	
R022	RD350000	CARBON RESISTOR (CHIP)	0 63M J RECT.	チ	ッ	ブ	抵	抗	
R031	RD455100	CARBON RESISTOR (CHIP)	100.0 63M J RECT.	チ	ッ	ブ	抵	抗	
R032	RD455100	CARBON RESISTOR (CHIP)	100.0 63M J RECT.	チ	ッ	ブ	抵	抗	
R038	RD455100	CARBON RESISTOR (CHIP)	100.0 63M J RECT.	チ	ッ	ブ	抵	抗	
R039	RD455100	CARBON RESISTOR (CHIP)	100.0 63M J RECT.	チ	ッ	ブ	抵	抗	
R053	RD45747R	CARBON RESISTOR (CHIP)	47.0K 63M J RECT.	チ	ッ	ブ	抵	抗	01
R055	RD45747R	CARBON RESISTOR (CHIP)	47.0K 63M J RECT.	チ	ッ	ブ	抵	抗	01
R057	RD45747R	CARBON RESISTOR (CHIP)	47.0K 63M J RECT.	チ	ッ	ブ	抵	抗	01
R059	RD45747R	CARBON RESISTOR (CHIP)	47.0K 63M J RECT.	チ	ッ	ブ	抵	抗	01
R066	RD45000R	CARBON RESISTOR (CHIP)	0.00 63M J RECT.	チ	ッ	ブ	抵	抗	01
R070	RD45747R	CARBON RESISTOR (CHIP)	47.0K 63M J RECT.	チ	ッ	ブ	抵	抗	01
R075	RF457220	CARBON RESISTOR (CHIP)	22.0K D RECT.	チ	ッ	ブ	抵	抗	
R077	RF456100	CARBON RESISTOR (CHIP)	1.0K D RECT.	チ	ッ	ブ	抵	抗	
R083	RD454470	CARBON RESISTOR (CHIP)	47.0 63M J RECT.	チ	ッ	ブ	抵	抗	01
R086	RD45747R	CARBON RESISTOR (CHIP)	47.0K 63M J RECT.	チ	ッ	ブ	抵	抗	01
R087	RD457220	CARBON RESISTOR (CHIP)	22.0K 63M J RECT.	チ	ッ	ブ	抵	抗	01
R088	RD457330	CARBON RESISTOR (CHIP)	33.0K 63M J RECT.	チ	ッ	ブ	抵	抗	01
R089	RD455100	CARBON RESISTOR (CHIP)	100.0 63M J RECT.	チ	ッ	ブ	抵	抗	
R093	RD357470	CARBON RESISTOR (CHIP)	47.0K 63M J RECT.	チ	ッ	ブ	抵	抗	
R094	RD357470	CARBON RESISTOR (CHIP)	47.0K 63M J RECT.	チ	ッ	ブ	抵	抗	
R095	RD356100	CARBON RESISTOR (CHIP)	1.0K 63M J RECT.	チ	ッ	ブ	抵	抗	01
R096	RD458100	CARBON RESISTOR (CHIP)	100.0K 63M J RECT.	チ	ッ	ブ	抵	抗	
R100	RD455330	CARBON RESISTOR (CHIP)	330.0 63M J RECT.	チ	ッ	ブ	抵	抗	
R102	RD454680	CARBON RESISTOR (CHIP)	68.0 63M J RECT.	チ	ッ	ブ	抵	抗	01
R105	RD454680	CARBON RESISTOR (CHIP)	68.0 63M J RECT.	チ	ッ	ブ	抵	抗	01
R108	RD454680	CARBON RESISTOR (CHIP)	68.0 63M J RECT.	チ	ッ	ブ	抵	抗	01
R110	RD454680	CARBON RESISTOR (CHIP)	68.0 63M J RECT.	チ	ッ	ブ	抵	抗	01
R111	RD454680	CARBON RESISTOR (CHIP)	68.0 63M J RECT.	チ	ッ	ブ	抵	抗	01
R115	RD455150	CARBON RESISTOR (CHIP)	150.0 63M J RECT.	チ	ッ	ブ	抵	抗	
R122	RD45000R	CARBON RESISTOR (CHIP)	0.00 63M J RECT.	チ	ッ	ブ	抵	抗	01
R123	RD454220	CARBON RESISTOR (CHIP)	22.0 63M J RECT.	チ	ッ	ブ	抵	抗	
R124	RD45000R	CARBON RESISTOR (CHIP)	0.00 63M J RECT.	チ	ッ	ブ	抵	抗	01
R125	RD454220	CARBON RESISTOR (CHIP)	22.0 63M J RECT.	チ	ッ	ブ	抵	抗	
-127	RD454220	CARBON RESISTOR (CHIP)	22.0 63M J RECT.	チ	ッ	ブ	抵	抗	
R133	RD454220	CARBON RESISTOR (CHIP)	22.0 63M J RECT.	チ	ッ	ブ	抵	抗	
R137	RD454680	CARBON RESISTOR (CHIP)	68.0 63M J RECT.	チ	ッ	ブ	抵	抗	01
R139	RD454680	CARBON RESISTOR (CHIP)	68.0 63M J RECT.	チ	ッ	ブ	抵	抗	01
R143	RD454680	CARBON RESISTOR (CHIP)	68.0 63M J RECT.	チ	ッ	ブ	抵	抗	01
R144	RD454100	CARBON RESISTOR (CHIP)	10.0 63M J RECT.	チ	ッ	ブ	抵	抗	01
R145	RD454680	CARBON RESISTOR (CHIP)	68.0 63M J RECT.	チ	ッ	ブ	抵	抗	01
R146	RD454100	CARBON RESISTOR (CHIP)	10.0 63M J RECT.	チ	ッ	ブ	抵	抗	01
R150	RD457100	CARBON RESISTOR (CHIP)	10.0K 63M J RECT.	チ	ッ	ブ	抵	抗	
R151	RD457100	CARBON RESISTOR (CHIP)	10.0K 63M J RECT.	チ	ッ	ブ	抵	抗	
R157	RD455100	CARBON RESISTOR (CHIP)	100.0 63M J RECT.	チ	ッ	ブ	抵	抗	
* R179	RA154270	METAL FILM RESISTOR (CHIP)	27.0 63M D RECT.	チ	ッ	ブ	金	被	抵
* R180	RA154270	METAL FILM RESISTOR (CHIP)	27.0 63M D RECT.	チ	ッ	ブ	金	被	抵
R181	RA154220	METAL FILM RESISTOR (CHIP)	22.0 63M D RECT.	チ	ッ	ブ	金	被	抵
R182	RA154220	METAL FILM RESISTOR (CHIP)	22.0 63M D RECT.	チ	ッ	ブ	金	被	抵
R186	RD456100	CARBON RESISTOR (CHIP)	1.0K 63M J RECT.	チ	ッ	ブ	抵	抗	
R190	RD455100	CARBON RESISTOR (CHIP)	100.0 63M J RECT.	チ	ッ	ブ	抵	抗	
R191	RD456100	CARBON RESISTOR (CHIP)	1.0K 63M J RECT.	チ	ッ	ブ	抵	抗	
R192	RD458470	CARBON RESISTOR (CHIP)	470.0K 63M J RECT.	チ	ッ	ブ	抵	抗	
R193	RD454680	CARBON RESISTOR (CHIP)	68.0 63M J RECT.	チ	ッ	ブ	抵	抗	01
R194	RD458470	CARBON RESISTOR (CHIP)	470.0K 63M J RECT.	チ	ッ	ブ	抵	抗	
R196	RD454680	CARBON RESISTOR (CHIP)	68.0 63M J RECT.	チ	ッ	ブ	抵	抗	01
R201	RD454680	CARBON RESISTOR (CHIP)	68.0 63M J RECT.	チ	ッ	ブ	抵	抗	01
-205	RD454680	CARBON RESISTOR (CHIP)	68.0 63M J RECT.	チ	ッ	ブ	抵	抗	01
R208	RD45000R	CARBON RESISTOR (CHIP)	0.00 63M J RECT.	チ	ッ	ブ	抵	抗	01
-211	RD45000R	CARBON RESISTOR (CHIP)	0.00 63M J RECT.	チ	ッ	ブ	抵	抗	01
R212	RD45522R	CARBON RESISTOR (CHIP)	220.0 63M J RECT.	チ	ッ	ブ	抵	抗	01
-214	RD45522R	CARBON RESISTOR (CHIP)	220.0 63M J RECT.	チ	ッ	ブ	抵	抗	01
R215	RD45000R	CARBON RESISTOR (CHIP)	0.00 63M J RECT.	チ	ッ	ブ	抵	抗	01
R217	RD457100	CARBON RESISTOR (CHIP)	10.0K 63M J RECT.	チ	ッ	ブ	抵	抗	
R218	RD45000R	CARBON RESISTOR (CHIP)	0.00 63M J RECT.	チ	ッ	ブ	抵	抗	01
R219	RD457100	CARBON RESISTOR (CHIP)	10.0K 63M J RECT.	チ	ッ	ブ	抵	抗	
R221	RD45000R	CARBON RESISTOR (CHIP)	0.00 63M J RECT.	チ	ッ	ブ	抵	抗	01
R222	RD454470	CARBON RESISTOR (CHIP)	47.0 63M J RECT.	チ	ッ	ブ	抵	抗	01

* : New Parts

RANK : Japan only

DM,GHL88H,GHL88L,GHL88M

REF NO.	PART NO.	DESCRIPTION	部 品 名	REMARKS	QTY	RANK
R225	RD454470	CARBON RESISTOR (CHIP)	47.0 63M J RECT.	チ ツ ブ 抵 抗		01
R240	RD45000R	CARBON RESISTOR (CHIP)	0.00 63M J RECT.	チ ツ ブ 抵 抗		01
R243	RD45000R	CARBON RESISTOR (CHIP)	0.00 63M J RECT.	チ ツ ブ 抵 抗		01
R244	RD45615R	CARBON RESISTOR (CHIP)	1.5K 63M J RECT.	チ ツ ブ 抵 抗		01
R245	RD456390	CARBON RESISTOR (CHIP)	3.9K 63M J RECT.	チ ツ ブ 抵 抗		
R246	RD455100	CARBON RESISTOR (CHIP)	100.0 63M J RECT.	チ ツ ブ 抵 抗		
R247	RD456100	CARBON RESISTOR (CHIP)	1.0K 63M J RECT.	チ ツ ブ 抵 抗		
R248	RD455100	CARBON RESISTOR (CHIP)	100.0 63M J RECT.	チ ツ ブ 抵 抗		
R250	RD458100	CARBON RESISTOR (CHIP)	100.0K 63M J RECT.	チ ツ ブ 抵 抗		
R251	RD45747R	CARBON RESISTOR (CHIP)	47.0K 63M J RECT.	チ ツ ブ 抵 抗		01
R254	RD456470	CARBON RESISTOR (CHIP)	4.7K 63M J RECT.	チ ツ ブ 抵 抗		
R269	RD457150	CARBON RESISTOR (CHIP)	15.0K 63M J RECT.	チ ツ ブ 抵 抗		01
R270	RD457150	CARBON RESISTOR (CHIP)	15.0K 63M J RECT.	チ ツ ブ 抵 抗		01
R275	RD354220	CARBON RESISTOR (CHIP)	22.0 63M J RECT.	チ ツ ブ 抵 抗		
R278	RD456360	CARBON RESISTOR (CHIP)	3.6K 63M J RECT.	チ ツ ブ 抵 抗		
R280	RD457100	CARBON RESISTOR (CHIP)	10.0K 63M J RECT.	チ ツ ブ 抵 抗		
-283	RD457100	CARBON RESISTOR (CHIP)	10.0K 63M J RECT.	チ ツ ブ 抵 抗		
R293	RD350000	CARBON RESISTOR (CHIP)	0 63M J RECT.	チ ツ ブ 抵 抗		
R294	RD457100	CARBON RESISTOR (CHIP)	10.0K 63M J RECT.	チ ツ ブ 抵 抗		
R295	RD456470	CARBON RESISTOR (CHIP)	4.7K 63M J RECT.	チ ツ ブ 抵 抗		
-297	RD456470	CARBON RESISTOR (CHIP)	4.7K 63M J RECT.	チ ツ ブ 抵 抗		
R299	RD350000	CARBON RESISTOR (CHIP)	0 63M J RECT.	チ ツ ブ 抵 抗		
R304	RD350000	CARBON RESISTOR (CHIP)	0 63M J RECT.	チ ツ ブ 抵 抗		
RA022	WH207000	RESISTOR ARRAY	100 X 4	抵 抗 ア レ イ		01
RA028	WH206200	RESISTOR ARRAY	47 X 4	抵 抗 ア レ イ		01
RA029	WH206200	RESISTOR ARRAY	47 X 4	抵 抗 ア レ イ		01
RA030	WH205600	RESISTOR ARRAY	27 X 4	抵 抗 ア レ イ		
-037	WH205600	RESISTOR ARRAY	27 X 4	抵 抗 ア レ イ		
RA044	WH212600	RESISTOR ARRAY	22K X 4	抵 抗 ア レ イ		01
RA045	WH207000	RESISTOR ARRAY	100 X 4	抵 抗 ア レ イ		01
RA046	WH209400	RESISTOR ARRAY	1.0K X 4	抵 抗 ア レ イ		
RA047	WH212600	RESISTOR ARRAY	22K X 4	抵 抗 ア レ イ		01
RA048	WH209400	RESISTOR ARRAY	1.0K X 4	抵 抗 ア レ イ		
RA049	WH209400	RESISTOR ARRAY	1.0K X 4	抵 抗 ア レ イ		
RA051	WH211800	RESISTOR ARRAY	10K X 4	抵 抗 ア レ イ		01
RA052	WH212600	RESISTOR ARRAY	22K X 4	抵 抗 ア レ イ		01
RA054	WH207000	RESISTOR ARRAY	100 X 4	抵 抗 ア レ イ		01
RA055	WH207000	RESISTOR ARRAY	100 X 4	抵 抗 ア レ イ		01
RA060	WH205400	RESISTOR ARRAY	22 X 4	抵 抗 ア レ イ		01
RA061	WH205400	RESISTOR ARRAY	22 X 4	抵 抗 ア レ イ		01
RA066	WH205400	RESISTOR ARRAY	22 X 4	抵 抗 ア レ イ		01
RA068	WH205400	RESISTOR ARRAY	22 X 4	抵 抗 ア レ イ		01
RA079	WH206600	RESISTOR ARRAY	68 X 4	抵 抗 ア レ イ		01
RA080	WH206600	RESISTOR ARRAY	68 X 4	抵 抗 ア レ イ		01
RA082	WH206600	RESISTOR ARRAY	68 X 4	抵 抗 ア レ イ		01
RA083	WH206600	RESISTOR ARRAY	68 X 4	抵 抗 ア レ イ		01
RA094	WH209400	RESISTOR ARRAY	1.0K X 4	抵 抗 ア レ イ		
RA095	WH211000	RESISTOR ARRAY	4.7K X 4	抵 抗 ア レ イ		01
TH1	V326060R	POLY-SWITCH	MICRO SMD035F-2 SMD	ボ リ ス イ ッ チ		02
TR001	WB12320R	TRANSISTOR (ARRAY)	IMB10A T110	ト ラ ン ジ ス タ ア レ イ		05
-004	WB12320R	TRANSISTOR (ARRAY)	IMB10A T110	ト ラ ン ジ ス タ ア レ イ		05
TR005	VY67760R	DIGITAL TRANSISTOR	DTC123JKA TP	デ ジ タ ル ト ラ ン ジ ス タ		01
TR006	WG989900	DIGITAL TRANSISTOR	KRA226S-RTK/P	デ ジ タ ル ト ラ ン ジ ス タ		01
X001	WA782100	CERAMIC RESONATOR 5M	5.000M	セ ラ ミ ッ ク 振 動 子		
X002	WM521200	QUARTZ CRYSTAL UNIT 48MHZ	SG-310SCF 48M	水 晶 振 動 器		04
X002	WM725500	RESONATOR QUARTZ 48MHz	48M DSO321SR	水 晶 発 振 器		
X003	WM135200	RESONATOR QUARTZ	16.9344M DSX321G	水 晶 振 動 子		
	WF21280R	CIRCUIT BOARD	GHL88H	G H L 8 8 シ ー ト H	(WF46250)(X6246D0)	12
CN1	WA61950R	CONNECTOR	52151 17P SE	ワ イ ヤ ー ト ラ ッ プ		01
D1	VB941200	DIODE	1SS133,1SS176 TE-5	ダ イ オ ー ド		
-48	VB941200	DIODE	1SS133,1SS176 TE-5	ダ イ オ ー ド		
	WF21250R	CIRCUIT BOARD	GHL88L	G H L 8 8 シ ー ト L	(WF46230)(X6244D0)	13
CN1	WA61950R	CONNECTOR	52151 17P SE	ワ イ ヤ ー ト ラ ッ プ		01
D1	VB941200	DIODE	1SS133,1SS176 TE-5	ダ イ オ ー ド		
D5	VB941200	DIODE	1SS133,1SS176 TE-5	ダ イ オ ー ド		
-60	VB941200	DIODE	1SS133,1SS176 TE-5	ダ イ オ ー ド		
	WF21260R	CIRCUIT BOARD	GHL88M	G H L 8 8 シ ー ト M	(WF46240)(X6245G0)	13

*: New Parts

RANK : Japan only

GHL88M,MKO,MVR,PEDAL,PNL,PNR,PWR

REF NO.	PART NO.	DESCRIPTION		部 品 名	REMARKS	QTY	RANK
CN1	WA61950R	CONNECTOR	52151 17P SE	ワ イ ヤ ー ト ラ ッ プ			01
CN2	WG01190R	CONNECTOR	52807 27P SE	F F C コ ネ ク タ			
CN3	WA61950R	CONNECTOR	52151 17P SE	ワ イ ヤ ー ト ラ ッ プ			01
D1	VB941200	DIODE	1SS133,1SS176 TE-5	ダ イ オ ー ド			
-72	VB941200	DIODE	1SS133,1SS176 TE-5	ダ イ オ ー ド			
	--	CIRCUIT BOARD	MKO	M K O シ ー ト	(ZE90270)(ZE90120) (YE943B0)		
*	ZE902200	CIRCUIT BOARD	MVR	M V R シ ー ト	(ZE90120)(YE943B0)		
*	ZE901900	CIRCUIT BOARD	PEDAL	P E D A L シ ー ト	(ZE90120)(YE943B0)		
*	ZE901500	CIRCUIT BOARD	PNL	P N L シ ー ト	(ZE90120)(YE943B0)		
*	ZE901700	CIRCUIT BOARD	PNR	P N R シ ー ト	(ZE90120)(YE943B0)		
*	ZE902100	CIRCUIT BOARD	PWR	P W R シ ー ト	(ZE90120)(YE943B0)		
CN1	V492820R	CONNECTOR	52806-1210 12P TE	F F C コ ネ ク タ ー			01
CN2	WG033600	CONNECTOR	52806 15P TE	F F C コ ネ ク タ			
CN3	VI878100	CONNECTOR	51048 3P TE	ケ ー ブ ル ホ ル ダ ー			
CN701	WK843700	CONNECTOR	52806 6P TE	F F C コ ネ ク タ ー			
CN901	VI878100	CONNECTOR	51048 3P TE	ケ ー ブ ル ホ ル ダ ー			
CN902	VK024800	CONNECTOR	52147 4P TE	ワ イ ヤ ー ト ラ ッ プ			
CN903	VI878000	CONNECTOR	51048 2P TE	ケ ー ブ ル ホ ル ダ ー			
D1	VB941200	DIODE	1SS133,1SS176 TE-5	ダ イ オ ー ド			
-8	VB941200	DIODE	1SS133,1SS176 TE-5	ダ イ オ ー ド			
EC1	VU48130R	ENCODER	REB161-PVB-15FH1NA	1 6 形 エ ン コ ー ダ	DATA ENTRY		03
JK701	V487480R	CONNECTOR	DINJACK6P MD-S6130	ミ ニ D I N コ ネ ク タ	PEDAL UNIT		02
L701	V2993400	COIL 20UH	R-5C TE-	チ ョ ー ク コ イ ル			01
-706	V2993400	COIL 20UH	R-5C TE-	チ ョ ー ク コ イ ル			01
LD1	WG913200	LED	BL-BEG201-LC22-21-	2 色 L E D	START/STOP		01
LD2	WU175600	LED	BL-B2141K-24F-FP7-	L E D	SONG/AUDIO		01
LD3	WU175600	LED	BL-B2141K-24F-FP7-	L E D	STYLE		01
LD4	WU175600	LED	BL-B2141K-24F-FP7-	L E D	USB TO DEVICE		01
R1	HF454270	CARBON RESISTOR	27.0 1/4 J AX TP	カ ー ボ ン 抵 抗			01
R2	HF45418R	CARBON RESISTOR	18.0 1/4 J AX TP	カ ー ボ ン 抵 抗			01
R3	HF455100	CARBON RESISTOR	100.0 1/4 J AX TP	カ ー ボ ン 抵 抗			
-5	HF455100	CARBON RESISTOR	100.0 1/4 J AX TP	カ ー ボ ン 抵 抗			
* SW64	WZ033500	PUSH SWITCH	ESE20D421	プ ッ シ ュ S W	STANDBY/ON		
VR603	WN157800	ROTARY VARIABLE RESISTOR DUAL	B 20.0K XV012313YG	2 連 ロ ー タ リ ー V R	MASTER VOLUME		01
WH101	--	WIRING ASSEMBLY	ENC	E N C 束 線	(ZF62920)		
WH102	--	WIRING ASSEMBLY	SSW	S S W 束 線	(ZF51060)		
	YF221A00	LOUD SPEAKER	5.0cm 6ohm 10W	ス ピ ー カ	Tweeter	2	
*	YF014A00	LOUD SPEAKER	12.0cm 4 ohm 10W	ス ピ ー カ	Woofers	2	
	WU967500	LCD UNIT		液 晶 ユ ニ ッ ト			17
△	WK014700	AC ADAPTOR	PA-150U U	A C ア ダ プ タ ー	U,C		08
△	WR527000	AC ADAPTOR	PA-150A E	A C ア ダ プ タ ー	E,I		10
△	WR527100	AC ADAPTOR	PA-150A B	A C ア ダ プ タ ー	B		11
△	WR527200	AC ADAPTOR	PA-150A CHN	A C ア ダ プ タ ー	DGX-650B O		
△	WU356400	AC ADOPTOR	PA-150A K	A C ア ダ プ タ ー	K		08

*: New Parts

RANK : Japan only

Pedal Unit

LP-7A/LP-7AWH

PARTS LIST

■ CONTENTS

OVERALL ASSEMBLY	24
------------------------	----

Note) DESTINATION ABBREVIATIONS



A: Australian model	O: Chinese model
B: British model	Q: South-east Asia model
C: Canadian model	T: Taiwan model
D: German model	U: U.S.A. model
E: European model	V: General export model (110V)
F: French model	W: General export model (220V)
H: North European model	N,X: General export model
I: Indonesian model	Y: Export model
J: Japanese model	K: Korean model
M: South African model	P: Brazilian model

■ WARNING

Components having special characteristics are marked  and must be replaced with parts having specifications equal to those originally installed.

- The numbers in “QTY” shows quantities for each unit.
- The parts with “-” in “Part No.” are not available as spare parts.
- This mark “}” in the REMARKS column means these parts are interchangeable.
- The second letter of the shaded () part number is I, not one.
- The second letter of the shaded () part number is O, not zero.

OVERALL ASSEMBLY



REF NO.	PART NO.	DESCRIPTION	部 品 名	REMARKS	QTY	RANK
30	WQ613000	OVERALL ASSEMBLY	総 組 立	LP-7A/LP-7AWH		
30	ZD198800	SCREW SET	ネ ジ セ ッ ト	LP-7A		04
30a	--	SPACER	ス ペ ー サ ー	(WQ53260)	2	
30b	--	SCREW MACHINE +TRUS	小 ネ ジ + T R U S	(WP09720)	2	
30c	--	SCREW MACHINE +TRUS	小 ネ ジ + T R U S	LP-7A	4	
30c	--	SCREW MACHINE +TRUS	小 ネ ジ + T R U S	LP-7AWH	4	
30d	--	CORD CLAMP SET	コードクランプセット	(WK89080)		
30da	VP59210R	CORD CLAMPER DKN-5B(VHB)	N K ク ラ ン プ		3	03
30da	WB090800	CORD CLAMPER	C S ク ラ ン プ		3	01
60	WQ705900	PEDAL ASSEMBLY	ペ ダ ル A s s ' y			12
* 80	WQ624300	PEDAL BOARD ASSEMBLY	ペ ダ ル 框 A s s ' y	LP-7A		
* 80	ZF998300	PEDAL BOARD ASSEMBLY	ペ ダ ル 框 A s s ' y	LP-7AWH		
	WQ705900	PEDAL ASSEMBLY	ペ ダ ル A s s ' y			12
P10	WJ568500	PEDAL PIECE	ペ ダ ル 本 体		3	07
P20	--	PEDAL CASE LOWER	ペ ダ ル ケ ー ス 下	(WJ56870)		
P30	WJ646400	PEDAL SPRING	ペ ダ ル ス プ リ ン グ		3	01
P40	--	PEDAL CASE UPPER	ペ ダ ル ケ ー ス 上	(WQ47860)		
P50	WJ568800	RUBBER CONTACT	ラ バ ー コ ン タ ク ト		3	07
P60	WJ983300	CIRCUIT BOARD	P E D A L シ ー ト			03
P60a	VB390100	CONNECTOR	ベ ー ス ポ ス ト			
P70	--	STOPPER STAY ASSEMBLY	ストッパーステー A s s ' y	(WJ86730)		
P70a	--	STOPPER STAY	ストッパーステー	(WJ64630)		
P70b	WJ867400	STOPPER FELT	ストッパー フェルト		3	01
P80	WJ961900	PK CABLE	P K ケ ー ブ ル			12
P90	WE774300	BIND HEAD B-TIGHT SCREW	B タ イ ト + B I N D		6	
P100	WM142600	ARTIFICIAL LEATHER	人 工 皮 革		3	01
P110	--	GREASE DRY	ハ ナ ー ル	(WR65030)		
P120	--	RUBBER FOOT	ペ ダ ル ゴ ム 脚	(WJ96240)	3	
P130	--	RUBBER FOOT REAR	ペ ダ ル ゴ ム 脚 後	(WJ96250)	2	
P140	--	PEDAL COVER PLATE	ペ ダ ル 蓋 金 具	(WK04350)		
P150	WF026000	FLAT HEAD TAPPING SCREW-B	B タ イ ト + F L A T		3	01
P160	WK720200	BIND HEAD TAPPING SCREW-B	B タ イ ト + B I N D		14	01
P170	--	PEDAL ANGLE	ペ ダ ル ア ン グ ル	(WP08600)	2	
P180	WE98120R	BIND HEAD TAPPING SCREW-B	B タ イ ト + B I N D		4	01

* : New Parts

RANK : Japan only

Portable Grand **DGX-650B/DGX-650WH**

OVERALL CIRCUIT DIAGRAM



DGX-650B



DGX-650WH


- OVERALL CIRCUIT DIAGRAM 1/7 (DM (1/4)) 1
- OVERALL CIRCUIT DIAGRAM 2/7 (DM (2/4)) 2
- OVERALL CIRCUIT DIAGRAM 3/7 (DM (3/4)) 3
- OVERALL CIRCUIT DIAGRAM 4/7 (DM (4/4)) 4
- OVERALL CIRCUIT DIAGRAM 5/7 (AJACK, MVR, PB, PWR) 5
- OVERALL CIRCUIT DIAGRAM 6/7 (DJACK, ENC, PEDAL, PNL, PNR, USB) 6
- OVERALL CIRCUIT DIAGRAM 7/7 (GHL88H, GHL88L, GHL88M) 7

DGX-650B/DGX-650WH

< Page 2 >

DGX-650B/DGX-650WH OVERALL CIRCUIT DIAGRAM 2/7 (DM (2/4))

DGX-650B/DGX-650WH




1
2
3
4
5
6
7
8
9
10
11
12


DGX-650B/DGX-650WH

■ DGX-650B/DGX-650WH OVERALL CIRCUIT DIAGRAM 4/7 (DM (4/4))

DM 4/4









■ DGX-650B/DGX-650WH OVERALL CIRCUIT DIAGRAM 5/7 (AJACK, MVR, PB, PWR)

DGX-650B/DGX-650WH**DGX-650B/DGX-650WH****DGX-650B/DGX-650WH**

■ DGX-650B/DGX-650WH OVERALL CIRCUIT DIAGRAM 6/7 (DJACK, ENC, PEDAL, PNL, PNR, USB)


DGX-650B/DGX-650WH




DGX-650B/DGX-650WH OVERALL CIRCUIT DIAGRAM 7/7 (GHL88H, GHL88L, GHL88M)

DGX-650B/DGX-650WH

GHL88L



GHL88M



to DM-CN001
<Page2:M10>

GHL88H

